



# **Operation Manual & Installation Manual**

---

**VHF RADIO (GMDSS)**

**NVR-3000**

## **GENERAL INFORMATION**

### **i. Copyright**

The entire contents in this user manual, including any future updates, revisions, and modifications, shall remain the property of NSR at all times. Unauthorized copies or reproduction of this manual, either in part or whole, in any form of print and electronic media, is prohibited. The contents herein can only be used for the intended purpose of this manual.

### **ii. Disclaimer**

NSR is devoted to publish and maintain this user manual. As we continue to improve our products to satisfy customers' needs, information in this document is subject to change without prior notice. NSR does not make any representations or warranties (implied or otherwise) regarding the accuracy and completeness of this document and shall in no event be liable for any loss of profit or any commercial damage, including but not limited to special, incidental, consequential, or other damage.

### **iii. Warning**

Any attempt to install or execute software not supplied by NSR on this device will result in the warranty being void. Any attempt to modify the software on this device in a way not specified by NSR will result in the warranty being void.

### **iv. Notice**

Please read this manual carefully to ensure proper use before installation and operation of the NVR-3000.

## MODIFY RECORD

No.	Modify by	Date	Paragraph	Version	Reason
1	Q/A	2020/10/21		01	First edition
2	Q/A	2021/04/12	all	02	General modification

# TABLE OF CONTENTS

<b>1. OVERVIEW .....</b>	<b>6</b>
1.1 Outline.....	6
1.2 Product Features.....	6
1.3 System Configuration .....	6
<b>2. BASIC OPERATION.....</b>	<b>8</b>
2.1 Panel Button Description.....	8
2.2 Power On/Off .....	8
2.3 Main Screen .....	9
2.4 Channel Watch Scan Screen.....	9
2.4.1 Dual Watch Scan.....	9
2.4.2 All Channel Scan.....	10
2.5 Brightness adjustment .....	11
2.6 Main Speaker On/Off .....	11
2.7 Auto Acknowledgement Setting.....	11
2.8 System Setting.....	12
2.8.1 Language .....	12
2.8.2 Print.....	12
2.8.3 Audio .....	12
2.8.4 Display Setting.....	14
2.8.5 Date/Time Setting .....	15
2.8.6 Position Setting.....	16
2.8.7 Timeout Setting.....	17
2.8.8 Port Setting .....	18
2.9 Address List.....	18
2.9.1 View an address.....	19
2.9.2 Add an address.....	19
2.9.3 Delete an address.....	21
2.9.4 Call to an address .....	21
2.10 Diagnostics.....	22
2.10.1 Program Version .....	22
2.10.2 LCD Test.....	23
2.10.3 Key Test.....	23
2.10.4 Audio Test.....	23
2.11 User Manager .....	24
2.11.1 Private Channel.....	25
2.11.2 Alert list .....	26
2.11.3 User Test.....	27
2.11.4 DSC Log .....	27
<b>3. VOICE OPERATION.....</b>	<b>28</b>
3.1 Channel Region Selection .....	28

3.2 Channel Setting .....	28
3.3 Transmit .....	30
3.4 Receive .....	31
<b>4. DSC OPERATION .....</b>	<b>33</b>
4.1 DSC Description .....	33
4.1.1 DSC Message.....	33
4.1.2 Audio Alarms.....	34
4.1.3 DSC Call Screens .....	35
4.2. DSC Distress Operation.....	37
4.2.1 Send a Distress Call .....	37
4.2.2 Receive a Distress Call .....	42
4.2.3 Relay a Distress Call .....	46
4.2.4 Cancel a Distress Call .....	50
4.3. DSC GENERAL CALLS .....	51
4.3.1 Individual Call .....	52
4.3.2 Group Call .....	59
4.3.3 All Ships Call .....	62
4.3.4 Position Call .....	65
4.3.5 Test Call .....	70
4.3.6 Polling Call .....	74
<b>5. INSTALLATION .....</b>	<b>76</b>
5.1 VHF Antenna.....	76
5.2 Transceiver.....	76
5.3 CONNECTION.....	76
5.3.1 POWER SUPPLY.....	76
5.3.2 GNSS DATA INPUT .....	76
5.3.3 CONNECT TO PRINTER.....	76
5.3.4 CONNECT TO (S)VDR .....	77
5.3.5 CONNECT TO INS/BAM.....	77
5.4 MMSI & ATIS ID Setting .....	77
<b>6. MAINTENANCE .....</b>	<b>79</b>
6.1 Maintenance.....	79
6.2 Simple Troubleshooting.....	79
6.3 Error Messages .....	79
<b>APPENDIX 1 TECHNICAL SPECIFICATIONS .....</b>	<b>80</b>
<b>APPENDIX 2 MENU TREE.....</b>	<b>82</b>
<b>APPENDIX 3 CHANNEL TABLES .....</b>	<b>83</b>
<b>APPENDIX 4 SENTENCE DISCRIPTION.....</b>	<b>89</b>
<b>APPENDIX 5 INSTALLATION DRAWINGS.....</b>	<b>98</b>

# 1. OVERVIEW

## 1.1 Outline

NVR-3000 is a ship borne radiotelephone equipment on VHF FM and designed for marine mobile service which provides function of VHF radiotelephone and digital selective calling (class A).

NVR-3000 conforms to the regulations of ITU-R M.493-15, IEC 61097-3:2017, IEC 61097-7:2018, IEC 62923-1:2018, IEC 62923-2:2018, IEC 60945.

It contains a VHF radio transceiver and a digital selective calling system and a dedicated digital selective calling receiver to comply with the ITU Radio Regulations. Channel numbers can be 2-digit or 4-digit to meet the latest regulation of IMO and ITU.

## 1.2 Product Features


NVR-3000 is the new generation of NSR VHF Radio. The main features of the NVR-3000 include:

- Large 7-inch color LCD with touch screen operation.
- Knob & touch screen operation.
- 4-digital channels available.
- DSC watching receiver integrated.
- Channels are scanned to sample any signal to be received.
- Audio interface to VDR.
- Data interface to INS (BAM System).
- Handset to be used.

## 1.3 System Configuration

No.	Name	Type	Q'ty	Remarks
<b>Standard</b>				
1	Transceiver Unit	NVR-3000	1	
2	Handset	NHS-200	1	
3	Accessories		1	
4	User Manual		1	
<b>Optional</b>				
1	Power Supply Unit	PS-10	1	
2	VHF Antenna	NVA100	2	
3	Thermal Printer	NPT-100	1	
4	External Speaker	NSK-100	1	
5	Microphone	MC100	1	
6	Flush Mount Brackets	NFB700	1	

The below figure is for the system diagram.



## 2. BASIC OPERATION

### 2.1 Panel Button Description



NVR-3000 can be operated by key & knob on panel or touch-screen operation.

When operating with knob, rotate to select an item on screen and press the knob to confirm the selection.


No.	Panel Button	Function
①	<b>VOLUME PUSH TO PWR</b>	<ul style="list-style-type: none"> <li>Adjust the volume of main speaker and handset (Clockwise: volume up, Anti-clockwise: volume down). Press to mute the audio of main speaker.</li> <li>Press to turn the power on or off.</li> </ul>
②	<b>DIM</b>	Dimmer key for LCD brightness control.
③	<b>PUSH TO ENTER</b>	<ul style="list-style-type: none"> <li>Press to switch the volume adjustment object between main speaker and handset in Main screen.</li> <li>Rotate to select menu items, select channel or SQL level. Push to confirm a selection.</li> </ul>
④	<b>DISTRESS</b>	Press and hold down the button 3 seconds to transmit the distress alert. <i>Note: The <b>DISTRESS</b> button is covered to prevent false alarm.</i>
⑤		Handset socket
⑥		Main speaker
⑦		LCD

### 2.2 Power On/Off

<ul style="list-style-type: none"> <li><b>Power On:</b> Press the <b>PUSH TO PWR</b> knob to turn on the power.</li> </ul>	<ul style="list-style-type: none"> <li><b>Power Off:</b> Press and hold down the <b>PUSH TO PWR</b> knob until the screen goes blank, approx. three seconds.</li> </ul>
--	---



## 2.3 Main Screen



No.	Indication	Meaning
1	MMSI	Own ship's ID (9 digits) <i>Note: Request service to set your MMSI.</i>
2	RX Signal Level	The signal level of receiving
3	Handset Volume	The volume of handset
4	Speaker Volume	The volume of speaker
5	Connection Icon	Connection status of Transceiver. Green: OK.
6	EPFS /EPFS (OFFLINE)/ EPFS (OVER 4H)/ MANUAL/ NO INFO	[EPFS]: The position and time data from EPFS; [EPFS (OFFLINE)]: Indicate no position data from EPFS for 15 minutes; [EPFS (OVER 4H)]: Indicate no position data from EPFS for 4 hours; [MANUAL]: Set the position and time manually; [NO INFO]: No position and time data.
7	DSC MSG	Compose DSC message.
8	CH16	Switch to the Main (radiotelephone) screen and set to CH16. <i>Note: This function is not available for PRIV (private) channel region.</i>
9	MENU	Open the Main Menu.
10	WX	Switch to WX (Weather) Channel.
11	MULTI	Set SCAN or DW (Dual Watching).
12	TASK	Back to the DSC task menu.
13	CH	Channel setting
14	REGION	Select channel region.
15	POWER	Power (LOW/HIGH) setting
16	SQL	Squelch (OFF/ON-SQL value) setting

## 2.4 Channel Watch Scan Screen

### 2.4.1 Dual Watch Scan

In Dual Watch, CH16 and an additional channel will be scanned for watching.


- Generally, CH16 will be sampled for 0.15s while the additional channel is sampled for 1.85s.
- When a signal is detected on CH16 during sampling, the scanning will stop and the receiver will stay on CH16

for receiving. As soon as the signal disappears on CH16, the scanning between two channels will restore.


- If a signal is detected on the additional channel during sampling, the transceiver will continue the sampling of 0.15s on CH16 every 2s when receiving on the additional channel. Whenever a signal is detected on CH16 during sampling, the transceiver will stay on CH16 for receiving, by ignoring the signal on the additional channel.

Procedures:

- ① Set the additional channel to be watched (for example CH18). Refer to Section 3.2 **Channel Setting**.



- ② Click [MULTI] - [DW] to start the scanning. The screen alternately switches between CH 16 and CH 18.




- ③ To stop scanning, click [MULTI] - [DW] again or click any other button on the screen.

### 2.4.2 All Channel Scan

In All Channel Scan, CH16 and all other channels will be scanned alternatively in a cycle of 0.15/1.8 seconds.

Click [MULTI] - [SCAN] to start the scanning of all channels cyclically, click again to stop the scanning.




**Note:** Transmitting is disabled during scanning.

## 2.5 Brightness adjustment

There are two ways to adjust the brightness of screen.

- ① Press the **DIM** button on panel to adjust the brightness by ten steps, or
- ② Click **[MENU]** and adjust the brightness in the **[MAIN MENU]: [SYSTEM]-[DISPLAY]-[LCD DIMMER]**. Click **[LCD DIMMER]** knob by 1 ~ 10 steps.


*Note: When the power is turned off, the last status of brightness is stored. Therefore, when the power is turned on, the screen will display with the last brightness before powered off.*



## 2.6 Main Speaker On/Off



There are three ways to turn on/off the main speaker (except in DSC communication, alarming and key buzzing).

- ① Rotate the **VOLUME** knob anti-clockwise to mute the main speaker;
- ② At any screen, shortly press the **VOLUME** knob to mute the main speaker, and press again to resume;
- ③ While **[AUDIO] - [OFF HOOK SPK]** in **[SYSTEM SETTING]** is set as **ON**, the main speaker keeps on no matter the handset is on/off the hook. While **[OFF HOOK SPK]** is set as **OFF**, the main speaker will be muted if the handset is off the hook. Refer to Section 2.8.3.3.



## 2.7 Auto Acknowledgement Setting

Individual, position, polling and test calls can be acknowledged automatically. This is to set on **[ACK SETTING]** in the **[MAIN MENU]-[DSC]** menu.



*Note: When own ship's communication is in high priority, set to manual acknowledgement.*


The auto acknowledgement is not sent in the following cases:

- There are DSC communications (for individual call).
- Channel is in use.

**Note:** *The auto acknowledgement for the individual call is sent only when the proposed channel or communication mode is available. “REASON” area gives the reason of AUTO-UNABLE correspondingly.*

## 2.8 System Setting

Click [SYSTEM] on the [MAIN MENU] screen. The following [SYSTEM SETTING] screen appears:



### 2.8.1 Language


The default menu language is English.

Click [LANGUAGE] to change the menu language.

### 2.8.2 Print

The [PRINT] menu enables/disables automatic printing of all transmitted and received calls and the results of the self-test.

- ① Click [PRINT] in [SYSTEM SETTING].
- ② Click [TX MESSAGE] to select **MANUAL** or **AUTO**.
- ③ Set [RX MESSAGE] and [SELFTEST INFO] similarly.
- ④ You can also set the printer type and port baud rate here.



### 2.8.3 Audio

Click [AUDIO] in [SYSTEM SETTING] to set the key buzzer and alarm buzzer etc.

#### 2.8.3.1 KEY BUZZER

Click [**KEY**] to switch the buzzer on or off.

[ AUDIO ]	
KEY	ON
SYSTEM ALARM	OFF
OFF HOOK SPK	OFF
SQL	ON
SQL LEVEL	09
BACK	

### 2.8.3.2 ALARM BUZZER

Click [**SYSTEM ALARM**] to switch the alarm buzzer on or off.

By setting the [**SYSTEM ALARM**], alarm that sounds against system faults and message receiving may be enabled or disabled.

[ AUDIO ]	
KEY	ON
SYSTEM ALARM	ON
OFF HOOK SPK	OFF
SQL	ON
SQL LEVEL	09
BACK	

### 2.8.3.3 OFF HOOK SPK

Click [**OFF HOOK SPK**] to switch the main speaker on or off when the handset is off-hook.

[ AUDIO ]	
KEY	ON
SYSTEM ALARM	ON
OFF HOOK SPK	OFF
SQL	ON
SQL LEVEL	09
BACK	

### 2.8.3.4 SQL

Click [SQL] to switch the SQL on or off.

[ AUDIO ]	
KEY	ON
SYSTEM ALARM	ON
OFF HOOK SPK	OFF
SQL	ON
SQL LEVEL	09
BACK	

### 2.8.3.5 SQL LEVEL

Click [SQL LEVEL] to select the threshold value between 1~10.

[ AUDIO ]	
KEY	ON
SYSTEM ALARM	ON
OFF HOOK SPK	OFF
SQL	ON
SQL LEVEL	09
BACK	

*Note: SQL can also be set on main screen.*

## 2.8.4 Display Setting

### 2.8.4.1 DISPLAY MODE


Set the display mode (DAY or NIGHT) in the [SYSTEM SETTING]-[DISPLAY]-[DISPLAY MODE] by clicking.

[ DISPLAY ]	
LCD DIMMER	1
DISPLAY MODE	DAY
CHANNEL SIZE	0000
BACK	

[ DISPLAY ]	
LCD DIMMER	6
DISPLAY MODE	NIGHT
CHANNEL SIZE	0000
BACK	

### 2.8.4.2 CHANNEL SIZE


There are two kinds of size can be selected. Click [CHANNEL SIZE] to change the size.




### 2.8.5 Date/Time Setting

This is to set the date and time for the system.

Click [DATE/TIME] in [SYSTEM SETTING] to open the [DATE/TIME SET] screen. There are four items can be set: MODE, DATE-UTC, TIME-UTC and ZONE.



- Date or time cannot be adjusted when they are input from GNSS navigator.
- If date or time is not input from GNSS navigator, click to enter date and time with the numeric keys in the pop-up window. For example:



[ DATE/TIME SET ]

MODE	UTC		INPUT		
DATE-UTC	2020-04-26		1	2	3
TIME-UTC	12:31:30		4	5	6
ZONE	+08:00		7	8	9
BACK			F	0	OK

[ DATE/TIME SET ]

MODE	UTC		INPUT		
DATE-UTC	2020-04-26		1	2	3
TIME-UTC	12:31:30		4	5	6
ZONE	1:+ 2:- +08:00		7	8	9
BACK			F	0	OK

**Note:** When manually enter date and time, use UTC (Universal Time Coordinated). Do not use local time (LMT).  
If LMT is selected, it will be showed on the bottom right of Main screen.

### 2.8.6 Position Setting

This is to set a position used for DSC operations only when GNSS input is not available.  
Do the following to set your position:

- ① Click [POSITION] in [SYSTEM SETTING]. The following screen appears:

[ POSITION ]

SOURCE	EPFS
POS&TIME	--°--'---- --°--'---- --:--
BACK	

- ② Click [SOURCE] to select [EPFS] or [MANUAL].  
[EPFS]: The position data from EPFS. The system will display “EPFS LOST POSITION” if no any data.



When [EPFS] is selected, position data will be input and updated from GNSS navigator connected.

[MANUAL]: Set the position data manually.

For [MANUAL], go to next step.

[ POSITION ]	
SOURCE	MANUAL
POS&TIME	00°00.0000N 000°00.0000E 00:00
BACK	

[ POSITION ]														
SOURCE	MANUAL	INPUT												
POS&TIME	00°00.0000N 000°00.0000E 00:00	<table border="1" style="margin: auto; border-collapse: collapse;"> <tr><td>1</td><td>2</td><td>3</td></tr> <tr><td>4</td><td>5</td><td>6</td></tr> <tr><td>7</td><td>8</td><td>9</td></tr> <tr><td>F</td><td>0</td><td>OK</td></tr> </table>	1	2	3	4	5	6	7	8	9	F	0	OK
1	2	3												
4	5	6												
7	8	9												
F	0	OK												
BACK														

- ③ For manual input, click [POS&TIME], use the numeric keys to enter latitude/longitude of your position, and UTC time. To change coordinate, click **1** for North or East; **2** for South or West. After entering each data, click **OK**.

[ POSITION ]														
SOURCE	MANUAL	INPUT												
POS&TIME	31°25.5566N 000°00.0000E 00:00	<table border="1" style="margin: auto; border-collapse: collapse;"> <tr><td>1</td><td>2</td><td>3</td></tr> <tr><td>4</td><td>5</td><td>6</td></tr> <tr><td>7</td><td>8</td><td>9</td></tr> <tr><td>F</td><td>0</td><td>OK</td></tr> </table>	1	2	3	4	5	6	7	8	9	F	0	OK
1	2	3												
4	5	6												
7	8	9												
F	0	OK												
BACK														

[ POSITION ]														
SOURCE	MANUAL	INPUT												
POS&TIME	31°25.5566N 120°31.7788E 00:00	<table border="1" style="margin: auto; border-collapse: collapse;"> <tr><td>1</td><td>2</td><td>3</td></tr> <tr><td>4</td><td>5</td><td>6</td></tr> <tr><td>7</td><td>8</td><td>9</td></tr> <tr><td>F</td><td>0</td><td>OK</td></tr> </table>	1	2	3	4	5	6	7	8	9	F	0	OK
1	2	3												
4	5	6												
7	8	9												
F	0	OK												
BACK	1:E 2:W													

**Note:** When the setting of POSITION input type is [MANUAL], and the message "WARNING: Position data is not updated!" is shown, the Position data was older than 4H. Please update it.

### 2.8.7 Timeout Setting

This is to set the time out parameters for some operations.

Click [TIMEOUT] in [SYSTEM SETTING]. The following screen appears:

[ TIMEOUT ]	
MENU BACK	OFF
TELEPHONE	30S
GENERAL DSC	15MIN
DISTRESS RX	15MIN
BACK	

- [MENU BACK]:** Back to the upper menu screen automatically.
- [TELEPHONE]:** Close the inactive communications for VHF telephone.
- [GENERAL DSC]:** Close the inactive communications except the distress call.
- [DISTRESS RX]:** Close the inactive communications for the receiving distress call.

Click to select the item and its time interval desired.

**[OFF]** leaves the menu screen and/or the inactive communications open until you close them manually.

### 2.8.8 Port Setting

This is to set the baud rate of I/O ports.

Click **[PORT]** in **[SYSTEM SETTING]**. The following screen appears. Click **[INS]**, **[GNSS]** or **[ALARM]** until the desired baud rate appears.

[ PORT ]	
INS	38400
GNSS	4800
ALARM	38400
BACK	

### 2.9 Address List

This is to build up a list of regularly used stations.

[ DSC ]	
MESSAGE	
ADDRESS	
SCAN SETTING	
ACK SETTING	
MMSI SETTING	
BACK	

Click **[ADDRESS]** in the **[MAIN MENU]-[DSC]** menu, you can do the following operations.

[ ADDRESS LIST ]				
NO	MMSI	TYPE	NAME	1 / 7
>01	004122100	COAST	SHANGHAI RADIO	^ ^ ^ ^ ^ ^ ^ v v v v v
02	004123100	COAST	GUANGZHOU RADIO	
03	004121100	COAST	TIANJIN RADIO	
04	004121300	COAST	DALIAN RADIO	
05	004122200	COAST	QINGDAO RADIO	
06	004122700	COAST	XIAMEN RADIO	
07	004773500	COAST	HONGKONG RADIO	

VIEW

ADD

DEL

CALL

BACK

### 2.9.1 View an address

- ① Click to select the address in list.
- ② Click **[VIEW]** to see the details of the address.

[ ADDRESS EDIT ]	
MMSI	004122100
TYPE	COAST
NAME	SHANGHAI RADIO
BACK	

The address can be edited in this menu.

### 2.9.2 Add an address

- ① Click **[ADD]** to add an address. For example, add a group MMSI.

[ ADDRESS EDIT ]	
MMSI	000000000
TYPE	SHIP
NAME	
BACK	

- ② Click **[MMSI]**, enter the MMSI with the numeric keys in **[INPUT]**.

[ ADDRESS EDIT ]		
<b>MMSI</b>	041288888	<b>INPUT</b>
<b>TYPE</b>	SHIP	1 2 3
<b>NAME</b>		4 5 6
<b>BACK</b>		7 8 9
		F 0 OK


- ③ Click **[OK]** to confirm. The **[TYPE]** is automatically changed to **GROUP** if you enter the group MMSI.
- ④ Click **[NAME]** to add a group name by using keys in **[INPUT]** and rotating the **[PUSH TO ENTER]** knob.

[ ADDRESS EDIT ]		
<b>MMSI</b>	041288888	<b>INPUT</b>
<b>TYPE</b>	GROUP	1 2 3 ABC DEF
<b>NAME</b>		4 5 6 GHI JKL MNO
<b>BACK</b>		7 8 9 PQRS TUV WXYZ
		F 0 OK Del _

- ⑤ Click **[OK]** to confirm the editing.

[ ADDRESS EDIT ]		
<b>MMSI</b>	041288888	<b>SAVE</b>
<b>TYPE</b>	GROUP	
<b>NAME</b>	GROUP 1	
<b>BACK</b>		

- ⑥ Click **[SAVE]** and select **[YES]**. The address is added in the list.




### 2.9.3 Delete an address


- ① Click to select an address in list.
- ② Click **[DEL]**, delete the selected address directly.

### 2.9.4 Call to an address

- ① Click to select an address in list.
- ② Click **[CALL]**, you can send a DSC call to the selected address. For example:
  - **To a coast station:** You can send **INDIVIDUAL** or **TEST** call.



- **To a group:** You can send **GROUP** call.



- **To a ship:** You can send **INDIVIDUAL**, **TEST** or **POSITION** call.

[ ADDRESS LIST ]				
NO	MMSI	TYPE	NAME	9/ 9
02	004123100	COAST	GUANGZHOU RADIO	CALL
03	004121300	COAST	DALIAN RADIO	INDIVIDUAL
04	004122200	COAST	QINGDAO RADIO	TEST
05	004122700	COAST	XIAMEN RADIO	POSITION
06	004773500	COAST	HONGKONG RADIO	VIEW
07	041288888	GROUP	GROUP 1	ADD
08	004121100	COAST	TIANJIN RADIO	DEL
>09	413888866	SHIP	NSR 1	CALL
BACK				

After editing, click [CALL] to send the DSC call.

## 2.10 Diagnostics

Click [DIAGNOSTICS] on the [MAIN MENU] screen. The following [DIAGNOSTICS] screen appears:

[ DIAGNOSTICS ]	
PROGRAM VERSION	
LCD TEST	
KEY TEST	
AUDIO TEST	
DSC RX TEST	
BACK	

### 2.10.1 Program Version

It is to check the program version at [DIAGNOSTICS] menu.

Click [PROGRAM VERSION], the following screen appears:


[ PROGRAM VERSION ]				
[ VHF RADIO ]				BACK
BOOT	:1.00	20210329		
APP	:1.00	20210329		
PA	:0.90	20210329		
[ HARDWARE ]				
FONT	:OK	PFONT:OK	FLASH:OK	SDRAM:OK
COMM	:OK	RTC :OK	TOUCH:OK	AUDIO:OK
NET	:OK			
TEST MODE:BUILD:Apr 11 2021 15:49:49				

### 2.10.2 LCD Test

After clicking [LCD TEST], press the **DIM** button to test the Display Brightness. Press the **PUSH TO ENTER** knob to return to the upper menu.

### 2.10.3 Key Test

It is designed to test whether the key, knob and touch-screen are working or not. Click [KEY TEST] to enter the following screen:



**KEY** test:

**DIM**: Press the **DIM** button.

**DISTRESS**: Press the **DISTRESS** button.

**KNOB** test:


**LEFT**/**RIGHT**/**ENT**: Turn the **PUSH TO ENTER** knob to left and right, then press it.

**LEFT2**/**RIGHT2**/**ENT2**: Turn the **PUSH TO PWR** knob to left and right, then press it.

**TOUCH** test: Touch the corner of the screen. The box corresponding to the item will be filled with blue color.

If everything is good, **OK** icon will appear.


Click [**BACK**] to return to the upper menu.



### 2.10.4 Audio Test

It is to check the audio at [**DIAGOSTICS**] menu.

Click [AUDIO TEST], the following screen appears:





Click the items to test the corresponding audio.

**Note:** 1. The ALARM buzzer should be set to ON while do the test.  
 2. The setting (ON or OFF) of [MIC LOOPBACK] (used for handset microphone loop test) won't be saved.

## 2.11 User Manager

Click [USER] on the [MAIN MENU] screen. The [USER MANAGER] menu appears.





### 2.11.1 Private Channel

Click [**PRIVATE CHANNEL**], the following screen appears:

[ PRIVATE CHANNEL ]					
CH	TYPE	TX kHz	RX kHz	1/ 2	
>001	SIMP	156800	156800		VIEW
002	S-DUP	156000	158000		ADD
				^^	DEL
				^^	CALL
				^^	BACK
				^^	
				^^	
				^^	
				^^	
				^^	

① View/Edit a private channel:

Move the cursor to the wanted channel, click [**VIEW**], the [**CHANNEL EDIT**] screen appears:

[ CHANNEL EDIT ]	
TYPE	SIMP
TX	156800 kHz
RX	156800 kHz
BACK	

You can click the **TYPE**, **TX** frequency or **RX** frequency to edit. For example:

[ CHANNEL EDIT ]		INPUT
TYPE	SIMP	1 2 3
TX	156800 kHz	4 5 6
RX	156800 kHz	7 8 9
BACK		F 0 OK

Click [**TX**], enter the TX frequency with the numeric keys in [**INPUT**]. Click [**OK**] to confirm the input. Click [**SAVE**] and choose “**YES**” to save the edition, “**NO**” to discard the edition.

- ② Add a channel: Click [**ADD**], open the [**CHANNEL EDIT**] screen. The operation is same as above.
- ③ Delete a channel: Move the cursor to the wanted channel. Click [**DELETE**], delete the channel directly.
- ④ Call: Move the cursor to the wanted channel. Click [**CALL**], open Main screen to start voice communication.

### 2.11.2 Alert list

Click [MAIN MENU] - [USER] - [ALERT LIST ], the following menu appears.

[ ALERT LIST ]				
ID	TIME	ALERT-DESCRIPTION	1 / 7	
>◀ 3122	07:33	DISTRESS RX		VIEW
! 3016	07:33	LOST POSITION	^^	MUTE
◀ 3115	07:33	IMPAIRED RADIO	^^	ACK
◀ 3008	07:33	TRANSCEIVER FAIL		LOG
✓ 3062	07:33	GENERAL FAULT		BACK
◀ 3062	07:33	SELFTTEST FAULT	vv	
! 3019	07:34	WRONG MMSI	vv	
TIME:UTC				

[VIEW]: Check the details of the alert selected.

[MUTE]: Mute the alert.

[ACK]: Acknowledge the alert.

[LOG]: Check the alert history.

For example:

[ ALERT VIEW ]		
ID	3122	RESET
CATEGORY	B	
PRIORITY	WARNING	
STATE	ACTIVE-UNACKNOWLEDGED	
TEXT	DISTRESS RX Receipt of distress call	
BACK		

**Note:** [RESET] is only used for DISTRESS RX alert reset.

Alert Mark Description Table:

MARK	PRIORITY	STATE
	ALARM	ACTIVE-UNACKNOWLEDGED
		ACTIVE-SILENCED
		ACTIVE-ACKNOWLEDGED
		ACTIVE-RESPONSIBILITY TRANSFERRED
		RECTIFIED-UNACKNOWLEDGED
	WARNING	ACTIVE-UNACKNOWLEDGED
		ACTIVE-SILENCED
		ACTIVE-ACKNOWLEDGED
		ACTIVE-RESPONSIBILITY TRANSFERRED
		RECTIFIED-UNACKNOWLEDGED
	CAUTION	ACTIVE-ACKNOWLEDGED

Alert Description Table:

Alert identifier	Alert instance	Alert category	Alert priority	Alert text	Additional information
3122	310	B	WARNING	DISTRESS RX	Receipt of distress call
3016	312	B	CAUTION	LOST POSITION	No position data received
3116	313	B	CAUTION	IMPAIRED RADIO	Antenna VSWR
3008	314	B	WARNING	TRANSCEIVER FAIL	Not Transmitting Check
3062	316	B	WARNING	GENERAL FAULT	HW error. Check equipment
3062	317	B	WARNING	SELFTEST FAULT	Built in self test failure
3019	318	B	CAUTION	WRONG MMSI	Check MMSI setting
3009	320	B	CAUTION	LOST TRANSCEIVER	Check transceiver


### 2.11.3 User Test

Click **[USER TEST]** on the **[USER MANAGER]** screen.

Click **[DAILY]** to open the **[DAILY TEST]** screen.

Then click **[TEST]** and confirm “YES” to start the test.




The test result will be shown after the test.



### 2.11.4 DSC Log

DSC log also can be checked at **[USER MANAGER]** menu.

Click **[DSC LOG]**, and then click **[LIST]** repeatedly to check these screens:




### 3. VOICE OPERATION

You can make a voice call at Main screen or from [MAIN MENU]-[USER]-[PRIVATE CHANNEL]-[CALL].

#### 3.1 Channel Region Selection

The channel region can be selected by clicking [REGION] on the main menu.



[INTL]: International Channel

[USA]: USA Channel

[CAN]: CANADA Channel

[IWW]: Inland Waterway Channel

[PRIV]: Private Channel


*Note: Up to 200 Private channels are available only for fishing or specially assigned channels.*

#### 3.2 Channel Setting


There are three ways to set the channel. See below for details:

*Note: To set the radiotelephone to CH16, click [CH16].*

① Click [CH], the mark appears:




Click [CH] again, the following screen appears:




Click the number (2 ~ 4 digits) to enter channel then click **OK**.

- ② Click the channel number in the center of the screen.




The following screen appears:




Click to choose the desired channel.

For example:




- ③ Rotate the **PUSH TO ENTER** knob to change the channel number directly while [SQL] is OFF, or mark appears on the left side of [CH].



### 3.3 Transmit

- **Transmitting power setting**

Click [POWER] to select [HIGH] (25W) or [LOW] (1W).



● **Handset Operation**

The handset controls voice communications. Press the PTT (push-to-talk) switch to talk, and release it to listen for response.


- ① Pick up the handset.
- ② Hold the handset close to your mouth, press the **PTT** switch and speak clearly.



**3.4 Receive**

● **Squelch on/off**

The squelch mutes the noise output in the absence of an incoming signal. Click **[SQL]** to alternately turn squelch on and off in **[MENU] – [SYSTEM SETTING] - [AUDIO]** menu. When radio noise is too jarring during stand-by condition, it can be muted by activating the squelch, and the threshold value (1~10) is displayed on Main screen.




● **SQL level**

The SQL level can be adjusted. Please refer to Section 2.8.3.5.

You can also do the following steps to adjust the squelch level.

- ① Click [CH], the mark appears.
- ② Rotate the **PUSH TO ENTER** knob to change the squelch level.



**Note:** While using the handset for communication, press the **PTT** switch to talk and release it to listen.



## 4. DSC OPERATION

### 4.1 DSC Description

DSC (Digital Selective Calling) is an important mean for emergency calls at sea. It's a part of GMDSS (Global Maritime Distress and Safety System) set by IMO (International Marine Organization).

DSC should be primarily used for distress, urgent and safety call and response to such calls, in addition, it can be used for general service between ship to ship and ship to shore station and if automatic service is provided for by coastal stations for direct access to shore-based public telephone network.

#### 4.1.1 DSC Message

Normally, the contents of a DSC call include Calling category, Station ID (MMSI), Priority, Communication mode, Communication channel (frequency), Position, DSC channel (frequency), End code.

- **Calling category**

DSC calls are roughly divided in two groups: distress calls and general (urgency, safety and routine) calls. Below are the types of DSC calls.

Call category	Call
DISTRESS	DISTRESS ALERT, DISTRESS RELAY ALL, DISTRESS RELAY INDIVIDUAL, DISTRESS RELAY INDIVIDUAL ACK, DISTRESS ACK, DISTRESS CANCEL ACK
GENERAL	MEDICAL MSG*, NEUTRAL MSG*, INDIVIDUAL MSG, TEST MSG, GROUP MSG, ALL SHIPS MSG, POSITION MSG, POLLING MSG

\*SPECIAL MSG: To send these messages, set [**SPECIAL DSC**] to [**ON**].

[ SYSTEM SETTING ]

LANGUAGE    ENG	SPECIAL DSC    ON
PRINT	AUDIO
DISPLAY	DATE/TIME
POSITION	TIMEOUT
PORT	BACK

- **Station ID (MMSI)**

Ship station ID: MIDxxxxxx

Coast station ID: 00MIDxxxx

Group ID: 0MIDxxxxxx

Above, MID (Maritime Identification Digits): Country code, x...x: Digital number.

- **Priority**

**Distress:** In grave and imminent danger and request immediate assistance.


**Urgency:** A very urgent call concerning safety of ship, aircraft or other vehicle or safety of person.

**Safety:** A call containing an important navigational or meteorological warning.

**Routine:** General calling.

- **Communication mode**

**TELEPHONE:** Telephone (F3E/G3E) by VHF radiotelephone



- **Communication channel**

**COMM CH:** Subsequent working channel used to call by VHF radiotelephone. The sending station may have the receiving station (ship or coast station) assign the channel to use.

- **Position**


**POSITION:** Position can be automatically or manually set.

- **End code**

The end of a DSC call is indicated with "EOS" (acknowledgement, acknowledgement required, no acknowledgement required).

### 4.1.2 Audio Alarms

When you receive a distress alert or general call addressed to own ship, the audio and visual alarms are released. The audio alarm can be silenced with any key on Main screen or **CLICK** on **[DSC INFO]**.




Alarm	Frequency (interval)
Distress Count Down	2000Hz 500ms, Silence 500ms
Two Tone (Distress)	2200Hz 250ms, 1300Hz 250ms
Distress Ack	2200Hz 500ms, 1300Hz 500ms
Urgency	2200Hz 250ms, Silence 250ms
Urgency Ack	2200Hz 500ms, Silence 500ms
General (Routine, Routine Ack)	750Hz 50ms, 650 Hz 50ms
Warning	2000Hz 250ms, 1500 Hz 250ms
System Alarm	2000Hz 250ms, Silence 250ms


### 4.1.3 DSC Call Screens

#### 4.1.3.1 RX calls

##### Distress alert:



##### Individual call:



The marks "\*", "-" appear on the DSC receiving screen in the following conditions:

- "\*" indicates a corrupt character in received data.
- "-" indicates missing digits after decimal point when receiving position data with no information for expansion (expansion: digits after decimal point).

##### *Examples:*

- 1) When receiving position data without expansion, the indication is "LAT: 12 °34N".
- 2) When receiving position data with expansion, the indication is "LAT: 12 °34.5678°N".
- 3) When receiving position data with no information for expansion, the indication is "LAT: 12 °34.----°N".

The contents of other types of RX calls are similar to that of the individual call.

### 4.1.3.2 TX calls

#### Distress alert:

[ DISTRESS ALERT ]	
<input type="text" value="NATURE"/>	UNDESIGNATED
<input type="text" value="POSITION"/>	31°25.1122N 120°31.3344E 01:48
<input type="text" value="COMM MODE"/>	TELEPHONE
<input type="text" value="COMM CH"/>	16
<input type="text" value="BACK"/>	
PRESS DISTRESS BUTTON TO SEND ALERT.	

#### Distress relay call:

[ DISTRESS RELAY ]	
<input type="text" value="TYPE"/>	RELAY INDIVIDUAL
<input type="text" value="TO"/>	-----
<input type="text" value="DISSTRESS ID"/>	NO INFO
<input type="text" value="NATURE"/>	UNDESIGNATED
<input type="text" value="POSITION"/>	NO INFO NO INFO NO INFO
<input type="text" value="BACK"/>	

#### Individual call:

[ COMPOSE MESSAGE ]	
<input type="text" value="MSG TYPE"/>	INDIVIDUAL
<input type="text" value="TO"/>	-----
<input type="text" value="PRIORITY"/>	ROUTINE
<input type="text" value="COMM MODE"/>	TELEPHONE
<input type="text" value="COMM CH"/>	06
<input type="text" value="BACK"/>	

The contents of other types of TX calls are similar to the above.

## 4.2. DSC Distress Operation


When own ship in distress:

- ① Press the **DISTRESS** button to send a distress call.
- ② Wait for the distress alert acknowledgement.
- ③ Communicate with the coast station.

### 4.2.1 Send a Distress Call

#### 4.2.1.1 By DISTRESS button with distress information not edited

- (1) Open the cover of **DISTRESS** button then press and keep the **DISTRESS** button for 3 seconds.



\*: The **DISTRESS** button is covered to prevent false alarm.


The audio alarm sounds while pressing the button, and the button flashes. The countdown message appears on the screen while pressing the **DISTRESS** button (3S → 2S → 1S ). For example:


With position information:

[ DISTRESS ALERT ]	
NATURE	UNDESIGNATED
POSITION	31°25.1122N 120°31.3344E 01:48
COMM MODE	TELEPHONE
COMM CH	16
BACK	
PRESS DISTRESS BUTTON TO SEND ALERT. KEEP FOR 3S	


No position information:

[ DISTRESS ALERT ]	
NATURE	UNDESIGNATED
POSITION	NO INFO NO INFO NO INFO
COMM MODE	TELEPHONE
COMM CH	16
BACK	
PRESS DISTRESS BUTTON TO SEND ALERT. KEEP FOR 2S	

Press the **DISTRESS** button after the countdown shows 1S, the distress call is sent. The audio alarm sounds for two seconds and the message "!"OWN DISTRESS!" appears. The screen shows the contents of the distress alert call. The **DISTRESS** button flashes and only the icon for DISTRESS transmission (  ) is displayed in the tab area.



(2) After the distress call has been sent, the screen changes as below. Wait to receive the distress acknowledge call from a coast station. The elapsed time since transmission is displayed. At this time, the icons for other DSC received messages except the distress acknowledge call are not displayed. You can only confirm them in the DSC log.





**Note:** The equipment automatically re-transmits the distress alert after 3 min 30 seconds to 4 min 30 seconds if doesn't receive the distress acknowledge call. Then awaits the distress acknowledge call. This is repeated until the distress call is acknowledged.



(3) Click **[OPTION]**, you can temporarily stop the countdown during next retransmission by selecting **[PAUSE]** in the user options area. **[Pause]** is displayed instead of the countdown indication at **[RESEND]** indication. To restart, click **[OPTION]** again, **[Pause]** indication changes to **[Start]**, select **[Start]**. The countdown restarts. You can also cancel the sending/resending by clicking **[Cancel]**.

For example:



- ① **[OPTION]- [Pause]:**



② [OPTION]- [Start]:




③ [OPTION]- [Cancel]:




Please see the details in Section 4.2.4 - Cancel a Distress Call.

(4) You can click [Resend] to resend the distress call.

Also, you can re-send the distress alert manually by pressing the **DISTRESS** button for 3 seconds.



(5) When the distress acknowledge call is received, the audio alarm sounds, the LED of **DISTRESS** button flashes and the icon for DISTRESS ACK received  appears. The screen changes as right.



① Click **CLICK** to silence the audio alarm. Then, the **DISTRESS** button stops flashing, and the pop-up message disappears.


② Communicate with the coast station via radiotelephone, following the instructions below:

- Say “MAYDAY” three times.
- Say “This is ...” name of own ship and call sign three times.
- Give nature of distress and assistance needed.
- Give description of own ship (type, color, number of persons onboard, etc.).


### 4.2.1.2 Send a distress call by DSC MSG with distress information edited

If you have a time to prepare the distress message, send the distress call as follows:

① Click **[DSC MSG]**, or click **[MENU]** and choose **[DSC] – [MESSAGE]**, then click **[DISTRESS ALERT]** in **[MESSAGE]**.



② Click **[NATURE]** to select nature of distress, among the following eleven selections:



Nature of Distress	Description
FIRE	Fire, explosion
FLOODING	Flooding
COLLISION	Collision
GROUNDING	Grounding
LISTING	Listing, in danger of capsizing
SINKING	Sinking
ADRIFT	Adrift
UNDESIGNATED	Undesignated distress
ABANDONING	Abandoning ship
PIRACY ATTACK	Piracy/armed robbery attack
MAN OVERBOARD	Man overboard



③ Click **[POSITION]**, select **[EPFS]**, **[MANUAL]** or **[NO INFO]** in pop-up window.

[ DISTRESS ALERT ]

NATURE	UNDESIGNATED	<b>POSITION</b>
<b>POSITION</b>	NO INFO NO INFO NO INFO	EPFS
COMM MODE	TELEPHONE	MANUAL
COMM CH	16	NO INFO
BACK		

PRESS DISTRESS BUTTON TO SEND ALERT.

**[EPFS]:** The position information from EPFS is automatically shown.

[ DISTRESS ALERT ]

NATURE	UNDESIGNATED	
<b>POSITION</b>	31°25.1122N 120°31.3344E 01:48	
COMM MODE	TELEPHONE	
COMM CH	16	
BACK		

PRESS DISTRESS BUTTON TO SEND ALERT.

**[MANUAL]:** Input your position manually.

[ DISTRESS ALERT ]

NATURE	UNDESIGNATED	<b>INPUT</b>
<b>POSITION</b>	31°25.1122N 120°31.3344E 01:48	1 2 3
COMM MODE	TELEPHONE	4 5 6
COMM CH	16	7 8 9
BACK		F 0 OK

PRESS DISTRESS BUTTON TO SEND ALERT.

**[NO INFO]:** No information.


[ DISTRESS ALERT ]

NATURE	UNDESIGNATED	
<b>POSITION</b>	NO INFO NO INFO NO INFO	
COMM MODE	TELEPHONE	
COMM CH	16	
BACK		


PRESS DISTRESS BUTTON TO SEND ALERT.

For **[MANUAL]**, go to step ④. For others, go to step ⑤.

- ④ Use the numeric keys to enter latitude/longitude of your position, and UTC time. To change coordinate, click **1** for North or East; **2** for South or West. After enter each data, click **OK**.
- ⑤ Press and keep the **DISTRESS** button for 3 seconds to send the distress alert and wait for the acknowledgement. This operation is same as Section 4.2.1.1.
- ⑥ When the distress acknowledge call is received, use the telephone to communicate with the coast station. Refer to Section 4.2.1.1 (5).




### 4.2.2 Receive a Distress Call

When you receive a distress call from a ship in distress, the audio alarm sounds, and the LED of the **DISTRESS** button flashes. The icon for DISTRESS receiving () appears in the tab area.




Click **CLICK** to silence the audio alarm. Wait for the distress acknowledgement from a coast station.



If you do not receive the distress acknowledgement from a coast station in about 5 minutes after receiving a distress call, please follow the flow charts in this section to determine your action.

**Note:** An asterisk (\*) appearing in a distress alert message indicates an error at the asterisk's location.




**Note:** You must wait at least 5 minutes before you can acknowledge the distress call so that the coast station has time to send a distress acknowledgement.

(1) Send the DSC distress acknowledgement to ship in distress :


If you do not receive the DSC distress acknowledgement from a coast station and you are able to aid the ship in distress, you may transmit the distress acknowledgement to the ship in distress after consulting with the RCC or a coast station.

**Send acknowledgement on CH70 as follows:**

- ① When you received a distress call, click **CLICK** to silence the audio alarm and stop the flashing of the LED.
- ② Wait 5 minutes after receiving a distress call.
- ③ If you do not receive the distress acknowledgement from a coast station and you have received the distress call more than twice, contact the ship in distress on CH16 according to the following procedure.
  - Say "MAYDAY".
  - Repeat MMSI of the ship in distress 3 times.
  - Say "This is..." (own ship's name)
  - Repeat MMSI of own ship 3 times
  - Say "RECEIVED MAYDAY".
- ④ Click **OPTION**, select **Ack**.



⑤ The following message appears on the screen.




⑥ Click **YES** to transmit the distress acknowledgement to the ship in distress.

**Note:** You can not edit the message for the distress acknowledgement.

(2) Send the distress relay to coast station:

① Click **[OPTION]**, select **[Relay]**, then click **YES** to open the composing screen for the distress relay.



② Click **[TYPE]** to select **[RELAY INDIVIDUAL]**.

③ Click **[TO]**, enter the MMSI of the coast station, where to send the distress relay, with the numeric keys then click **OK** to confirm.

[ DISTRESS RELAY ]

TYPE	RELAY INDIVIDUAL	INPUT
TO	004122100	1   2   3
DISSTRESS ID	413888777	4   5   6
NATURE	FIRE	7   8   9
POSITION	31°25. ----N 120°35. ----E 11:11	F   0   OK
BACK		CALL

④ Click [CALL], the screen changes to the [TX MESSAGE-RELAY INDIVIDUAL] for transmitting as following. After transmitting, the [WAIT ACK] screen appears.

<div style="border: 1px solid gray; padding: 2px; font-size: small;"> <span style="float: right;">DSC TX CH:70 INTL HIGH SIMP 25W</span> </div> <div style="border: 1px solid gray; padding: 5px;"> <p>[ TX MESSAGE-RELAY INDIVIDUAL ]</p> <p>PRIORITY :DISTRESS TO :004122100 DISTRESS :413888777 NATURE :FIRE POSITION :31°25N 120°35E 11:11 COMM MODE:TELEPHONE COMM CH :16</p> </div> <div style="border: 1px solid gray; padding: 2px; font-size: small;"> <span style="float: right;">[SENDING ] ELAPSED :00:00:01</span> </div> <div style="border: 1px solid gray; padding: 2px; font-size: small; text-align: center;"> <span style="background-color: #00a0e3; color: white; padding: 2px;">DSC MSG</span> <span style="background-color: #00a0e3; color: white; padding: 2px;">CH16</span> <span style="background-color: #00a0e3; color: white; padding: 2px;">MENU</span> <span style="background-color: #00a0e3; color: white; padding: 2px;">TAB</span> <span style="background-color: #00a0e3; color: white; padding: 2px;">PRINT</span> <span style="background-color: #00a0e3; color: white; padding: 2px;">OPTION</span> </div>	<div style="border: 1px solid gray; padding: 2px; font-size: small;"> <span style="float: right;">FM CH:16 INTL HIGH SIMP 25W</span> </div> <div style="border: 1px solid gray; padding: 5px;"> <p>[ TX MESSAGE-RELAY INDIVIDUAL ]</p> <p>PRIORITY :DISTRESS TO :004122100 DISTRESS :413888777 NATURE :FIRE POSITION :31°25N 120°35E 11:11 COMM MODE:TELEPHONE COMM CH :16</p> </div> <div style="border: 1px solid gray; padding: 2px; font-size: small;"> <span style="float: right;">[WAIT ACK ] ELAPSED :00:00:06</span> </div> <div style="border: 1px solid gray; padding: 2px; font-size: small; text-align: center;"> <span style="background-color: #00a0e3; color: white; padding: 2px;">DSC MSG</span> <span style="background-color: #00a0e3; color: white; padding: 2px;">CH16</span> <span style="background-color: #00a0e3; color: white; padding: 2px;">MENU</span> <span style="background-color: #00a0e3; color: white; padding: 2px;">TAB</span> <span style="background-color: #00a0e3; color: white; padding: 2px;">PRINT</span> <span style="background-color: #00a0e3; color: white; padding: 2px;">OPTION</span> </div>
--	---


When the distress relay individual acknowledgement from the coast station is received, the audio alarm sounds and a pop-up message appears. Click **CLICK** to silence the alarm and erase the pop-up message. Communicate with the coast station by telephone, over the channel specified. If you do not receive the distress acknowledgement from a coast station, click [OPTION], select [RESEND] to transmit the distress relay again, or select [Quit] to finish the distress relay. You can also transmit the distress relay (refer to 4.2.3) again.

(3) Send the distress relay to all ships:

- ① Click [OPTION], select [Relay] , then click **YES** to open the composing screen for the distress relay.
- ② Click [TYPE] to select [RELAY ALL SHIP].

<div style="border: 1px solid gray; padding: 2px; font-size: small;"> <span style="float: right;">FM CH:16 INTL HIGH SIMP 25W</span> </div> <div style="border: 1px solid gray; padding: 5px;"> <p>[ RX MESSAGE-DISTRESS ALERT ]</p> <p style="background-color: #00a0e3; color: white; padding: 2px; font-weight: bold;">DSC INFO</p> <p style="font-size: x-small;">DISTRESS :413888777 NATURE :FIRE POSITION :31°25N 120°35E 11:11 COMM MODE:TELEPHONE COMM CH :16</p> <p style="text-align: center; font-weight: bold;">ARE YOU SURE SEND RELAY? 3' HAVE NOT PASSED.</p> <p style="text-align: center;">NO   YES</p> </div> <div style="border: 1px solid gray; padding: 2px; font-size: small;"> <span style="float: right;">[WAIT ACK ] ELAPSED :00:00:30</span> </div> <div style="border: 1px solid gray; padding: 2px; font-size: small; text-align: center;"> <span style="background-color: #00a0e3; color: white; padding: 2px;">DSC MSG</span> <span style="background-color: #00a0e3; color: white; padding: 2px;">CH16</span> <span style="background-color: #00a0e3; color: white; padding: 2px;">MENU</span> <span style="background-color: #00a0e3; color: white; padding: 2px;">TAB</span> <span style="background-color: #00a0e3; color: white; padding: 2px;">PRINT</span> <span style="background-color: #00a0e3; color: white; padding: 2px;">OPTION</span> </div>	<div style="border: 1px solid gray; padding: 5px;"> <p style="text-align: center;">[ DISTRESS RELAY ALLSHIP ]</p> <table style="width: 100%; border-collapse: collapse;"> <tr><td style="border: 1px solid gray;">TYPE</td><td>RELAY ALL SHIP</td></tr> <tr><td style="border: 1px solid gray;">TO</td><td>ALL SHIP</td></tr> <tr><td style="border: 1px solid gray;">DISSTRESS ID</td><td>413888777</td></tr> <tr><td style="border: 1px solid gray;">NATURE</td><td>FIRE</td></tr> <tr><td style="border: 1px solid gray;">POSITION</td><td>31°25. ----N 120°35. ----E 11:11</td></tr> <tr><td style="border: 1px solid gray;">BACK</td><td style="text-align: right; background-color: #00a0e3; color: white;">CALL</td></tr> </table> </div>	TYPE	RELAY ALL SHIP	TO	ALL SHIP	DISSTRESS ID	413888777	NATURE	FIRE	POSITION	31°25. ----N 120°35. ----E 11:11	BACK	CALL
TYPE	RELAY ALL SHIP												
TO	ALL SHIP												
DISSTRESS ID	413888777												
NATURE	FIRE												
POSITION	31°25. ----N 120°35. ----E 11:11												
BACK	CALL												

③ Click [CALL], then click **YES** to send the relay call, the screen changes to the [TX MESSAGE-RELAY ALL SHIP] for transmitting as following. After transmitting, the [WAIT ACK] screen appears.



## 4.2.3 Relay a Distress Call


### 4.2.3.1 Send distress relay to coast station

You can send the distress relay to a coast station on behalf of a ship in distress in the following cases:


- You are near the ship in distress and the ship in distress cannot transmit the distress alert.
- When the master or person responsible for own ship considers that further assistance is necessary.

**Note:** Do not use the **DISTRESS** button to relay distress.

- ① Click **[DSC MSG]** or **[MENU]-[DSC]-[MESSAGE]**.



- ② Click **[DISTRESS RELAY]** in the **[MESSAGE]** menu to open the composing screen for the distress relay.



- ③ Click **[TYPE]** to select **[RELAY INDIVIDUAL]**.

[ DISTRESS RELAY ]	
<input type="text" value="TYPE"/>	RELAY INDIVIDUAL
<input type="text" value="TO"/>	-----
<input type="text" value="DISSTRESS ID"/>	NO INFO
<input type="text" value="NATURE"/>	UNDESIGNATED
<input type="text" value="POSITION"/>	NO INFO NO INFO NO INFO
<input type="text" value="BACK"/>	

- ④ With **[TO]** selected, click to enter the MMSI where to send the distress relay by numeric keys in **[INPUT]**. Click **[OK]** to confirm.

[ DISTRESS RELAY ]														
<input type="text" value="TYPE"/>	RELAY INDIVIDUAL	<input type="text" value="INPUT"/>												
<input type="text" value="TO"/>	004122100	<table border="1" style="width: 100%; text-align: center;"> <tr><td>1</td><td>2</td><td>3</td></tr> <tr><td>4</td><td>5</td><td>6</td></tr> <tr><td>7</td><td>8</td><td>9</td></tr> <tr><td>F</td><td>0</td><td>OK</td></tr> </table>	1	2	3	4	5	6	7	8	9	F	0	OK
1	2	3												
4	5	6												
7	8	9												
F	0	OK												
<input type="text" value="DISSTRESS ID"/>	NO INFO													
<input type="text" value="NATURE"/>	UNDESIGNATED													
<input type="text" value="POSITION"/>	NO INFO NO INFO NO INFO													
<input type="text" value="BACK"/>														

- ⑤ Click **[DISSTRESS ID]**, choose **[INPUT]** to enter the ID (MMSI) of the ship in distress with the numeric keys then click **[OK]**.

[ DISTRESS RELAY ]		
<input type="text" value="TYPE"/>	RELAY INDIVIDUAL	<input type="text" value="DISSTRESS ID"/>
<input type="text" value="TO"/>	413000001	<input type="text" value="INPUT"/>
<input type="text" value="DISSTRESS ID"/>	NO INFO	<input type="text" value="NO INFO"/>
<input type="text" value="NATURE"/>	UNDESIGNATED	
<input type="text" value="POSITION"/>	NO INFO NO INFO NO INFO	
<input type="text" value="BACK"/>		<input type="text" value="CALL"/>

[ DISTRESS RELAY ]														
<input type="text" value="TYPE"/>	RELAY INDIVIDUAL	<input type="text" value="INPUT"/>												
<input type="text" value="TO"/>	004122100	<table border="1" style="width: 100%; text-align: center;"> <tr><td>1</td><td>2</td><td>3</td></tr> <tr><td>4</td><td>5</td><td>6</td></tr> <tr><td>7</td><td>8</td><td>9</td></tr> <tr><td>F</td><td>0</td><td>OK</td></tr> </table>	1	2	3	4	5	6	7	8	9	F	0	OK
1	2	3												
4	5	6												
7	8	9												
F	0	OK												
<input type="text" value="DISSTRESS ID"/>	413000000													
<input type="text" value="NATURE"/>	UNDESIGNATED													
<input type="text" value="POSITION"/>	NO INFO NO INFO NO INFO													
<input type="text" value="BACK"/>		<input type="text" value="CALL"/>												

- ⑥ With **[NATURE]** selected, click to select nature of distress.

[ DISTRESS RELAY ]		
TYPE	RELAY INDIVIDUAL	NATURE
TO	004122100	FIRE
DISSTRESS ID	413888777	FLOODING
NATURE	UNDESIGNATED	COLLISION
POSITION	NO INFO NO INFO NO	GROUNDING
BACK		LISTING
		SINKING
		ADRIFT
		UNDESIGNATED
		ABANDONING
		PIRACY ATTACK
		MAN OVERBOARD
		EPIRB EMISSION
		CALL

- ⑦ With [POSITION] selected, click to select [EPFS], [MANUAL] or [NO INFO]. For [MANUAL], go to step ⑧. For others, go to step ⑨.

[ DISTRESS RELAY ]		
TYPE	RELAY INDIVIDUAL	POSITION
TO	004122100	EPFS
DISSTRESS ID	413888777	MANUAL
NATURE	FIRE	NO INFO
POSITION	NO INFO NO INFO NO INFO	
BACK		CALL


- ⑧ Use the numeric keys to enter latitude and longitude of the ship in distress. Switch coordinates: Click **1** to switch to North (East for longitude); **2** to switch to South (West for longitude). Also, enter the UTC time then click **OK** to confirm.
- ⑨ Click [CALL], the distress relay is transmitted to the coast station. After transmitting, the [WAIT ACK] screen appears. The elapsed time since transmitting is displayed.

[ TX MESSAGE-RELAY INDIVIDUAL ]	
PRIORITY :DISTRESS TO :004122100 DISTRESS :413888777 NATURE :FIRE POSITION :31°25.1122N 120°31.3344E 03:06 COMM MODE:TELEPHONE COMM CH :16	
[SENDING ]	ELAPSED :00:00:01
DSC MSG	CH16 MENU TAB PRINT OPTION

[ TX MESSAGE-RELAY INDIVIDUAL ]	
PRIORITY :DISTRESS TO :004122100 DISTRESS :413888777 NATURE :FIRE POSITION :31°25.1122N 120°31.3344E 03:06 COMM MODE:TELEPHONE COMM CH :16	
[WAIT ACK ]	ELAPSED :00:00:06
DSC MSG	CH16 MENU TAB PRINT OPTION

When the distress relay individual acknowledgement from the coast station is received, the audio alarm sounds and a pop-up message appears. Click **CLICK** to silence the alarm and erase the pop-up message. Communicate with the coast station by telephone. If you do not receive the distress acknowledgement from a coast station, click **OPTION** to select further operation.





**[Hold]:** You can hold the distress relay ( changes to ) and activate it again by clicking **[OPTION]**.

**Note:** If you click **[CH16]** to Main screen, the operation is held automatically, and click **[TASK]** to return to DSC screen.

**[Quit]:** You can finish the distress relay. Click **[YES]** to return to Main screen.

**[Relay]:** You can send the distress relay call to others.

**[Resend]:** You can resend the distress relay.


**[History]:** View the history.

The above option functions are the same as in other DSC calls.


### 4.2.3.2 Send a distress relay to all ships

If a coast station directs you to send a distress relay to all ships, follow the procedure as below. You can not transmit a distress relay unless directed by a coast station.

- ① Click **[DISTRESS RELAY]** in the **[MESSAGE]** menu to open the composing screen for the distress relay. Click **[TYPE]** to select **[RELAY ALL SHIP]**.



- ② With **[DISTRESS ID]** selected, enter the ID (MMSI) of the ship in distress. Refer to Section 4.2.3.1 ⑤.
- ③ With **[NATURE]** selected, click to select nature of distress. Refer to Section 4.2.3.1⑥.
- ④ With **[POSITION]** selected, enter latitude and longitude of the ship in distress. Refer to Section 4.2.3.1 ⑦~⑧.
- ⑤ Click **[CALL]**, the following message appears on the screen.




- ⑥ Click **YES**, the distress relay is transmitted to all ships.


### 4.2.4 Cancel a Distress Call

You can cancel the distress call while it is being sent or while waiting for its acknowledgement as follows.


- ① Click **[OPTION]**, then select **[Cancel]**.




- ② Click **YES** to cancel, the sending screen appears:




- ③ Pick up the handset, make a voice announcement with all ships via radiotelephone referring to the message on screen.



④ Click **[FINISH]** to finish the operation.



⑤ Click **[OPTION]** to select the further operation.



### 4.3. DSC GENERAL CALLS


The procedure for sending and receiving non-distress DSC messages is similar among different message types. The following is an example of the procedure for an individual call.

- ① Send the individual call.
- ② Wait for the individual message acknowledgement.
- ③ Start the communication.


### 4.3.1 Individual Call

The individual call is for calling a specific station. After sending an individual call, called ACK RQ transmission, wait to receive the acknowledge back (ACK BQ) signal from the receiving station.


#### 4.3.1.1 Send an individual call



- (1) Click **[DSC MSG]**, or click **[MENU]** and choose **[DSC] – [MESSAGE]**, then click **[GENERAL MESSAGE]** in **[MESSAGE]**.



- (2) Click **[MSG TYPE]** or rotate the **PUSH TO ENTER** knob to select **[MSG TYPE]** then push the knob, select **[INDIVIDUAL]** among INDIVIDUAL, GROUP, ALL SHIP, POSITION and TEST.



- (3) With **[TO]** selected, enter the MMSI where to send the call with the numeric keys in **[INPUT]**. Click **[OK]** to confirm.

[ COMPOSE MESSAGE ]																	
MSG TYPE	INDIVIDUAL	<table border="1"> <thead> <tr> <th colspan="3">INPUT</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>2</td> <td>3</td> </tr> <tr> <td>4</td> <td>5</td> <td>6</td> </tr> <tr> <td>7</td> <td>8</td> <td>9</td> </tr> <tr> <td>F</td> <td>0</td> <td>OK</td> </tr> </tbody> </table>	INPUT			1	2	3	4	5	6	7	8	9	F	0	OK
INPUT																	
1	2		3														
4	5		6														
7	8		9														
F	0		OK														
TO	413888777																
PRIORITY	ROUTINE																
COMM MODE	TELEPHONE																
COMM CH	06																
BACK																	
		CALL															

- (4) Click **[PRIORITY]** to select **[PRIORITY]** then push the knob, select **[ROUTINE]**, **[SAFETY]** or **[URGENCY]**.


[ COMPOSE MESSAGE ]		
MSG TYPE	INDIVIDUAL	
TO	413888777	
PRIORITY	SAFETY	
COMM MODE	TELEPHONE	
COMM CH	06	
BACK		
		CALL

- (5) The **[COMM MODE]** is **[TELEPHONE]** automatically.


- (6) Click **[COMM CH]**, use the numeric keys to enter the VHF channel and click **[OK]** to confirm. For example:

[ COMPOSE MESSAGE ]																	
MSG TYPE	INDIVIDUAL	<table border="1"> <thead> <tr> <th colspan="3">INPUT</th> </tr> </thead> <tbody> <tr> <td>1</td> <td>2</td> <td>3</td> </tr> <tr> <td>4</td> <td>5</td> <td>6</td> </tr> <tr> <td>7</td> <td>8</td> <td>9</td> </tr> <tr> <td>F</td> <td>0</td> <td>OK</td> </tr> </tbody> </table>	INPUT			1	2	3	4	5	6	7	8	9	F	0	OK
INPUT																	
1	2		3														
4	5		6														
7	8		9														
F	0		OK														
TO	413888777																
PRIORITY	SAFETY																
COMM MODE	TELEPHONE																
COMM CH	06																
BACK																	
		CALL															


- (7) Click **[CALL]** to send the individual call.




The timer starts counting up the time since the call is sent. After the call is sent, the equipment waits for acknowledgement of the call, showing the [WAIT ACK] screen as below.



You can also do the option: [Hold]/[Quit]/[Resend].



(8) When the ACK is received, the audio alarm sounds and the pop-up message appears on the screen as below. The timer starts counting up the time since the ACK is received.




There are three types of ACK messages: [INDIVIDUAL ACK], [INDIVIDUAL ACK] (NEW CH) and [UNABLE ACK].

(9) Do one of the following depending on the message type shown at step (9).

● **Individual acknowledge call received:**

- ① Click **CLICK** to silence the audio alarm and erase the pop-up message.
- ② The working channel is automatically set; you can communicate by radiotelephone (pick up the handset to talk).





③ After you have completed communications, click **OPTION**, select **Quit** to Main screen.

● **Individual acknowledge call (new channel) received:**

This call means that the station you sent the individual call to accepts your call, but requests their channel.



- ① Click **CLICK** to silence the audio alarm and erase the pop-up message. You can do the communication on the new channel, whichever the station requests.



② After you have completed communications, click [OPTION], select [Quit] to Main screen.

● **Unable to acknowledge call received:**

① Click [CLICK] to silence the audio alarm and erase the pop-up message. The reason for [UNABLE ACK] is displayed on the screen.



**Reason for unable to acknowledge**

NO REASON	CONESTION*
BUSY	QUEUE
STA. BARRED	NO OPERATOR
TEMP. NO ONE	EUT DISABLED
CH UBABLE	MODE UBABLE

\*: Coast station use

② Click [OPTION], select [Quit] to Main screen.

**Note:** If the coast station sends the message "QUEUE", wait until your turn comes.

If there is no response from the receiving station, do one of the following procedures:

**Resend call:** Click [OPTION], select [Resend].

**Cancel call:** Click [OPTION], select [Quit], then select [Yes] to cancel the call.

**4.3.1.2 Receive an individual call**

Unable acknowledge is sent automatically or manually depending on the acknowledgement method setting. Able acknowledge is sent only manually.

**Note:** The handset must be on hook and all sessions must be quit to enable automatic acknowledge.




- **Send unable acknowledge automatically:**

If you cannot use the channel specified by the sending station, an unable acknowledge [CH UNABLE] is sent automatically. The [ACK SETTING] menu is set to [AUTO-UNABLE]. It takes a few seconds to transmit the call.


- **Send able/unable acknowledge manually:**

When an individual call is received with the setting [MANUAL] on the [ACK SETTING] menu, the audio alarm sounds and a pop-up message appears on the screen as below.




Click **CLICK** to silence the audio alarm and erase the pop-up message.

There are three types of ACK transmission; able acknowledge, able to change channel and unable acknowledge. Click **OPTION**, follow the appropriate procedure as bellow.



**(1) Send able acknowledge call**


① Click **Accept**, send the able acknowledge call.




- ② Communicate by radiotelephone.
- ③ After you have completed communications, click **[OPTION]** to select **[Quit]**.

**(2) Send unable acknowledge call**

- ① Click **[Unable]**.



- ② With **[REASON]** selected, click **[CALL]** to send unable acknowledge call.



**(3) Send able acknowledge call and change channel**

- ① Click **[Propose]**, the following screen appears.



- ② Click **[COMM CH]**.

[ COMPOSE MESSAGE ]

MSG TYPE	INDIVIDUAL ACK	INPUT
TO	413888777	1 2 3
PRIORITY	SAFETY	4 5 6
COMM MODE	TELEPHONE	7 8 9
COMM CH	06	F 0 OK
BACK		CALL

- ③ Set the channel by the numeric keys and click **OK** to confirm. For example, CH06.
- ④ Click **[CALL]**, send the able to change channel acknowledge call.

DSC TX CH: 70 INTL SIMP HIGH 25W

[ TX MESSAGE-INDIVIDUAL ACK ]

PRIORITY : SAFETY  
TO : 413888777  
COMM MODE: TELEPHONE  
COMM CH : 06

[SENDING ] ELAPSED : 00:00:24

DSC MSG CH16 MENU TAB PRINT OPTION

FM CH: 06 INTL SIMP HIGH 25W

[ TX MESSAGE-INDIVIDUAL ACK ]

PRIORITY : SAFETY  
TO : 413888777  
COMM MODE: TELEPHONE  
COMM CH : 06

[FINISHED ] ELAPSED : 00:00:30

DSC MSG CH16 MENU TAB PRINT OPTION

- ⑤ Communicate by radiotelephone.
- ⑥ After you have completed communications, click **[OPTION]** to select **[Quit]**.

### 4.3.2 Group Call

Group call is used to call a specific group by specifying its group MMSI.

#### 4.3.2.1 Send a group call

MMSI 413000000

TX SIMP DISTRESS

16

CH	
INTL	REGION
HIGH 25W	POWER
09	SQL

EPFS 31°25.1122'N [UTC] 2021-04-11 01:15:21  
120°31.3344'E 01:15

DSC MSG CH16 MENU WX MULTI TASK

- (1) Click **[DSC MSG]**, or click **[MENU]** and choose **[DSC] – [MESSAGE]**, then click **[GENERAL MESSAGE]**

in [MESSAGE].

[ MESSAGE ]

DISTRESS ALERT

DISTRESS RELAY

GENERAL MESSAGE

BACK

(2) Click [MSG TYPE] to select [GROUP].

(3) With [TO] selected, enter the group MMSI that where to send the group call in [INPUT], then click **OK** to confirm.

[ COMPOSE MESSAGE ]

MSG TYPE	GROUP	INPUT												
TO	080000000	<table style="width: 100%; text-align: center; border-collapse: collapse;"> <tr><td style="border: 1px solid gray; padding: 2px;">1</td><td style="border: 1px solid gray; padding: 2px;">2</td><td style="border: 1px solid gray; padding: 2px;">3</td></tr> <tr><td style="border: 1px solid gray; padding: 2px;">4</td><td style="border: 1px solid gray; padding: 2px;">5</td><td style="border: 1px solid gray; padding: 2px;">6</td></tr> <tr><td style="border: 1px solid gray; padding: 2px;">7</td><td style="border: 1px solid gray; padding: 2px;">8</td><td style="border: 1px solid gray; padding: 2px;">9</td></tr> <tr><td style="border: 1px solid gray; padding: 2px;">F</td><td style="border: 1px solid gray; padding: 2px;">0</td><td style="border: 1px solid gray; padding: 2px;">OK</td></tr> </table>	1	2	3	4	5	6	7	8	9	F	0	OK
1	2	3												
4	5	6												
7	8	9												
F	0	OK												
PRIORITY	ROUTINE													
COMM MODE	TELEPHONE													
COMM CH	06													
BACK		CALL												



(4) [PRIORITY] is automatically selected to [ROUTINE].

(5) Click [COMM CH], set the channel by the numeric keys and click **OK** to confirm. For example, CH06.

[ COMPOSE MESSAGE ]

MSG TYPE	GROUP	INPUT												
TO	080000000	<table style="width: 100%; text-align: center; border-collapse: collapse;"> <tr><td style="border: 1px solid gray; padding: 2px;">1</td><td style="border: 1px solid gray; padding: 2px;">2</td><td style="border: 1px solid gray; padding: 2px;">3</td></tr> <tr><td style="border: 1px solid gray; padding: 2px;">4</td><td style="border: 1px solid gray; padding: 2px;">5</td><td style="border: 1px solid gray; padding: 2px;">6</td></tr> <tr><td style="border: 1px solid gray; padding: 2px;">7</td><td style="border: 1px solid gray; padding: 2px;">8</td><td style="border: 1px solid gray; padding: 2px;">9</td></tr> <tr><td style="border: 1px solid gray; padding: 2px;">F</td><td style="border: 1px solid gray; padding: 2px;">0</td><td style="border: 1px solid gray; padding: 2px;">OK</td></tr> </table>	1	2	3	4	5	6	7	8	9	F	0	OK
1	2	3												
4	5	6												
7	8	9												
F	0	OK												
PRIORITY	ROUTINE													
COMM MODE	TELEPHONE													
COMM CH	06													
BACK		CALL												

(6) After finish setting, click [CALL] to send the group call. The screen changes as below.





Communicate by radiotelephone.

- (7) After you have completed communications, click [OPTION], select [Quit] and click **YES** to Main screen.
- (8) You can also do the option: [Hold] or/[Resend].


### 4.3.2.2 Receive a group call

Group MMSI must be registered in order to receive a group call. Refer to Section 2.10.

When a group call is received, the audio alarm sounds. The icon () appears in the tab area, and the pop-up message "RECEIVED A DSC MESSAGE. GROUP" appears.



- (1) Click **CLICK** to silence the audio alarm and erase the pop-up message. The channel is automatically tuned to the received channel.




- (2) Watch on the channel. Communicate by radiotelephone.
- (3) After you have completed communications, click **[OPTION]** to select **[Quit]**.

### 4.3.3 All Ships Call


The purpose of an all ships call is to send an urgency or safety call to all ships for assistance within the area you designate. After sending the call, you can communicate by radiotelephone. Do the following before beginning actual communications:

- **URGENCY** priority: Say "PAN" three times followed by own ship's call sign.
- **SAFETY** priority: Say "SECURITE" three times followed by own ship's call sign.


#### 4.3.3.1 Send an all ships call




- (1) Click **[DSC MSG]**, or click **[MENU]** and choose **[DSC]** – **[MESSAGE]**, then click **[GENERAL MESSAGE]** in **[MESSAGE]**.



- (2) Click **[MSG TYPE]** to select **[ALL SHIP]**.
- (3) Click **[PRIORITY]** to select **[URGENCY]** or **[SAFETY]**.
- (4) Click **[COMM CH]**, set the channel by the numeric keys and click **[OK]** to confirm. For example, CH16.



(5) Click [CALL] to send the call. The screen changes as below.




Communicate by radiotelephone.


(6) After you have completed communications, click [OPTION], select [Quit] and click **YES** to Main screen.


(7) You can also do the option: [Hold] or [Resend].






### 4.3.3.2 Receive an all ships call

When you receive an all ships call, the audio alarm sounds. The icon  appears in the tab area, and the pop-up message "RECEIVED A DSC MESSAGE. ALL SHIP" appears.



- (1) Click **CLICK** to silence the audio alarm and erase the pop-up message. The channel is automatically tuned to the received communication channel.




- (2) Watch on the channel. Communicate by radiotelephone.
- (3) After you have completed communications, click **OPTION** to select **Quit**.



### 4.3.4 Position Call

There are two types of position calls: own ship requests another ship's position and other station requires own ship's position.


- Request position of other station:



- Send own ship's position to other station:




#### 4.3.4.1 Request other ship's position




- (1) Click [DSC MSG], or click [MENU] and choose [DSC] – [MESSAGE], then click [GENERAL MESSAGE] in [MESSAGE].




- (2) Click [MSG TYPE] to select [POSITION].
- (3) Click [TO], enter the MMSI where to send the position call in [INPUT], then click **OK** to confirm.




- (4) [PRIORITY] is automatically selected to [SAFETY].
- (5) Click [CALL] to send position call. The screen changes as below.



- (6) After the call has been sent, the [WAIT ACK] screen appears as below. The elapsed time since sending the call is displayed.




You can also do the option during waiting acknowledgement: **[Hold]**, **[Quit]** or **[Resend]**.




(7) When you receive an acknowledge message, the audio alarm sounds and a popup message appears.



(8) Click **CLICK** to silence the audio alarm and erase the pop-up message.



(9) Click [OPTION], select [Quit] to back to Main screen.



#### 4.3.4.2 Receive a position request call

You can enable automatic acknowledge of position request with [POSITION] on the [ACK SETTING] menu.


- **Automatic reply**


When another ship requests your position and the setting of [POSITION] on the [ACK SETTING] menu is [AUTO], the equipment automatically transmits a reply.

There are two types of automatic replies: one with position information (the setting is [AUTO -ABLE]) and the other with no position information (the setting is [AUTO -UNABLE]).


- **Manual reply**

When a position request message is received and the setting of [POSITION] on the [ACK SETTING] menu is [MANUAL], send the reply manually.


When you receive a position request call, the audio alarm sounds. The icon () appears in the tab area, and the pop-up message "RECEIVED A DSC MESSAGE. POSITION" appears.





(1) To silence the audio alarm, click **CLICK**.





(2) Click **[OPTION]**, do the operation as follows.



- Send the ACK with position information:  
Click **[Accept]**, send position information of own ship.




- Send the ACK with no position information:  
Click **[Unable]**. The screen changes as below.



- (3) After the ACK is finished, click **[OPTION]** to select **[Quit]**.

### 4.3.5 Test Call

#### 4.3.5.1 Send a test call




- (1) Click **[DSC MSG]**, or click **[MENU]** and choose **[DSC]** – **[MESSAGE]**, then click **[GENERAL MESSAGE]** in **[MESSAGE]**.




(2) Click [MSG TYPE] to select [TEST].


(3) Click [TO], enter the MMSI where to send the test call in [INPUT], then click **OK** to confirm.




(4) Click [CALL] to send test call. The screen changes as below.




(5) After the call has been sent, the [WAIT ACK] screen appears as below. The elapsed time since sending the call is displayed.



(6) When you receive an acknowledge message, the audio alarm sounds and a popup message appears.



(7) Click **CLICK** to silence the audio alarm and erase the pop-up message.



(8) Click **[OPTION]**, select **[Quit]** to back to Main screen.

### 4.3.5.2 Receive a test call


- **Automatic acknowledge**


When a test call is received with **[AUTO]** setting on **[TEST]** of the **[ACK SETTING]** menu, an acknowledgement is sent automatically.




● **Manual reply**

When a test call is received and the setting of [TEST] on the [ACK SETTING] menu is [MANUAL], send the acknowledgement manually.


When you receive a test call, the audio alarm sounds. The icon () appears in the tab area, and the pop-up message "RECEIVED A DSC MESSAGE. TEST" appears.




(1) To silence the audio alarm, click **CLICK**.



(2) Click [OPTION], choose one of the operations: [Hold], [Quit] or [Accept].



If you click **[Accept]**, the test acknowledgement will be sent.



After the acknowledgement is finished, click **[OPTION]** to select **[Quit]**.

### 4.3.6 Polling Call


Polling means that another ship wants to confirm if it is within communication range of own ship.


#### 4.3.6.1 Automatic reply

When a polling request message is received with **[AUTO]** setting on **[POLLING]** of the **[ACK SETTING]** menu, an acknowledgement is sent automatically.


#### 4.3.6.2 Manual reply

When a polling call is received and the setting of **[POLLING]** on the **[ACK SETTING]** menu is **[MANUAL]**, send the acknowledgement manually.


When you receive a polling request message, the audio alarm sounds. The icon () appears in the tab area, and the pop-up message "RECEIVED A DSC MESSAGE POLLING" appears.




(1) To silence the audio alarm, click **CLICK**.



(2) Click **[OPTION]**, choose one of the operations: **[Hold]**, **[Quit]** or **[Accept]**.



If you click **[Accept]**, the polling acknowledgement will be sent.



After the acknowledgement is finished, click **[OPTION]** to select **[Quit]**.

## 5. INSTALLATION

### 5.1 VHF Antenna

There are two VHF antennas to be connected.

It's very important to choose a proper location for VHF antenna as a metal object close to the antenna could affect receiving sensitivity.

**The following instructions are helpful:**

- The antenna should be kept at least 0.5m from a vertical metal object to avoid RF reflection.
- The antenna should be kept at least 3m from other high power radiator, such as radar antenna.
- Two VHF antennas should not be installed at the same height. One VHF antenna can be installed either under or above another VHF antenna. The distance between should be more than 2.8m. If two antennas have to be installed at the same height, the distance between should be more than 10m.

**For the cabling, please refer to below suggestions:**

- The shorter the cable, the less the loss. The low-loss cable is recommended if the cable is longer than 10m.
- Watertight treatment is required for outdoor connecting.
- The RF cable should be kept at least 10cm from the power cable. The cable cross should be avoided.

### 5.2 Transceiver

Four screws are supplied to mount the transceiver. The transceiver can be installed either on table or on wall.

Care must be taken when mounting the transceiver to ensure that there is sufficient space for cables and connectors. Especially, sharp bending of the RF cable must be avoided.

## 5.3 CONNECTION

### 5.3.1 POWER SUPPLY

The power cable with a rated capacity of 10A should be used. Suggest using NSR PS-10 Power Supply Unit (DC 24V output).

### 5.3.2 GNSS DATA INPUT

The input data format should be NMEA0183/4800bps, as IEC61162-1 standard. Refer to the installation drawings.

### 5.3.3 CONNECT TO PRINTER

As an optional device, NSR NPT-100 is recommended as the printer used for NVR-3000.

- Part No. : **NPT-100**
- Rating : **DC6.5V, 15W**

Necessary settings are needed for NPT-100 before properly working with NVR-3000. Please refer to the manual supplied by the printer maker. The settings include the following parameters:

**- Serial port setting**

The output of NPT-100 should be set as SERIAL.

**- Baud rate setting**

NPT-100's baud rate can be 75, 110, 150, 300, 600, 1200, 2400, 4800, 9600, 19200bps. As the default rate, both NVR-3000 and NPT-100 have been set at 4800bps in factory.

### 5.3.4 CONNECT TO (S)VDR

Please refer to the attached drawings for the connection and wiring.

### 5.3.5 CONNECT TO INS/BAM


Please refer to the attached drawings for the connection and wiring.

## 5.4 MMSI & ATIS ID Setting


When the VHF radio is powered on for the first time, typically during installation, the vessel's MMSI number can be entered. Hereafter the MMSI number is briefly displayed after powered on. The MMSI is a unique, 9-digit identifier assigned to own ship.

Do the following to set own ship's MMSI.


- ① Click [MENU] – [DSC] – [MMSI SETTING] on Main screen.




- ② With [MMSI] selected, the screen shown below appears. Click [MMSI]/[ATIS ID] to enter the MMSI/ATIS ID. Click **OK** to confirm the input.



③ Click [MMSI LOCK] / [ATIS ID LOCK] and choose **YES** to confirm the setting. And MMSI/ATIS ID will be locked afterwards. For example: ATIS LOCK.



The “**ATIS LOCK**” appears after clicking [ATIS LOCK] again.



**NOTE:** Without a programmed MMSI, the **DISTRESS** button will not work! The [DSC MSG] cannot be opened either if the MMSI has not been programmed during installation.

To change or reprogram a new MMSI, please contact NSR or local agent.

## 6. MAINTENANCE

### 6.1 Maintenance

Regular maintenance helps to keep your equipment in good condition and prevents future problems. Check the items shown in the table below.

Item	Check point	Remedy/Remarks
Antenna	Check for physical damage and corrosion.	Replace damaged parts.
Transceiver unit	<ul style="list-style-type: none"> <li>● Check grounding and cable connections.</li> <li>● Remove dust from the transceiver unit with soft cloth.</li> </ul> <p><i>Note: Do not use chemical cleaners to clean the transceiver unit; they can remove paint or markings and deform the equipment.</i></p>	<ul style="list-style-type: none"> <li>● Tighten loosened connections.</li> <li>● Wipe the LCD carefully to prevent scratching, using tissue paper and an LCD cleaner. To remove dirt or salt deposits, use an LCD cleaner, wiping slowly with tissue paper so as to dissolve the dirt or salt. Change paper frequently so the salt or dirt does not scratch the LCD.</li> </ul>
Power supply	Check that the supply voltage at transmission is within the rated range (21.6 to 31.2 VDC at the input of Power Supply Unit).	If not within the range, check power source. Low or over voltage may cause operation abnormal.

### 6.2 Simple Troubleshooting

The table below provides possible problems and the means with which to restore normal operation. If normal operation cannot be restored, do not attempt to check inside the equipment. Any servicing should be referred to a qualified technician.

Problem	Probable cause	Remedy
Power cannot be turned on.	<ul style="list-style-type: none"> <li>● Mains switchboard is off.</li> <li>● (DC) voltage is too high.</li> </ul>	<ul style="list-style-type: none"> <li>● Turn on the mains switchboard.</li> <li>● Check supply voltage.</li> </ul>
Dark display.	Display brightness is too low.	Press the <b>DIM</b> button to adjust the display brightness.
Power is on but no sound from the main speaker.	Main speaker is off.	Press the <b>VOLUME</b> knob to turn on the main speaker.

### 6.3 Error Messages

The table below shows error messages, their meanings, and remedies. Please refer to section 2.11.2. If other error occurs, contact your dealer.

Error message	Meaning	Remedy
WRONG MMSI	You tried to send a DSC message but your MMSI has not been registered in the equipment.	Enter MMSI of own ship.
GENERAL FAULT	HW error. Check equipment.	Check Version menu
LOST POSITION	Position data is not updated for 15 minutes.	Check external GNSS data input or enter the position.

## APPENDIX 1 TECHNICAL SPECIFICATIONS

### General Specifications

TX Frequency	156.025-157.425MHz
RX Frequency	156.050-163.275MHz
Number of Channels	ITU channel: 52 channels USA channel: 46 channels CAN channel: 75 channels IWW channel:52 channels WX (Weather): channel: 10 channels PRV (Private) channel : Maximum 200 channels
Channel Spacing	25 kHz
Communication Modes	Simplex and Semi-duplex press talk system
Type of Emission	Radiotelephone communications: F3E (G3E) DSC/ATIS: F2B (G2B)
Antenna Impedance	50 $\Omega$ unbalanced
Tx/Rx Switching Interval	300 ms or less
LCD display	7 inch color LCD, touch screen operation
Interface	IEC61162-1 Ed.5 (2016-08) IEC61162-2 Ed.1 (1998-09) 600 $\Omega$ balanced (VDR) 600 $\Omega$ unbalanced (Ext SP)
Performance Criteria	IMO A.803 (19), A.694 (17), MSC.68 (68), MSC/Circ.862 IEC 60945 Ed.4 (2002-08)
Power Supply Voltage	24 VDC (21.6 VDC - 31.2 VDC)
Current Consumption /Power(24VDC)	When transmitting at 25W: Maximum 4.5 A/108 W When receiving: Maximum 1.5 A/36 W
Operating Temperature Range	-15 $^{\circ}$ C ~ +55 $^{\circ}$ C (parts exposed to condensation -25 $^{\circ}$ C - +55 $^{\circ}$ C)
Storage Temperature Range	-15 $^{\circ}$ C ~ +55 $^{\circ}$ C (parts exposed to condensation -25 $^{\circ}$ C - +70 $^{\circ}$ C)
Humidity Resistance	No abnormalities after left for 10 hours at +40 $^{\circ}$ C, 93% RH
IP grade	IP22 ( Transceiver Unit, Handset) IP66 (Antenna)
Compass safe distance	1.2m (between Transceiver Unit and standard compass) 1.1m (between Transceiver Unit and steering compass) 0.35m (between Handset and standard compass) 0.3m (between Handset and steering compass)
Size and weight	<b>Transceiver Unit:</b> 146.9 (H) x 311.4 (W) x 81 (D) mm, about 3kg

### Transmitter

Output Power	25W (High), 1W (Low)
Maximum Frequency Shift	$\leq \pm 5$ kHz
Modulation Type	FM (pre-emphasis 6dB/octave)
Frequency Error	$\leq \pm 1.5$ kHz
Occupied Frequency Band	$\leq \pm 16$ kHz
Spurious Emission	$\leq 2.5\mu$ W (less than -26dBm)
Frequency Stability	$\leq \pm 10 \times 10^{-6}$
Upper Audio Limit	$\leq 3$ kHz

### Receiver

Sensitivity	$\leq 2\mu$ V e.m.f (SINAD=20dB)
Adjacent Selectivity	$\geq 70$ dB



Signal To Noise Ratio	$\geq 40\text{dB}$ ( 1kHz, 70% modulated, 30dB $\mu\text{V}$ RF input)
Spurious Response Rejection	$\geq 70\text{dB}$
Spurious Emission	$\leq 2\text{nW}$ (9kHz ~ 2GHz)
Intermodulation Rejection	$\geq 65\text{dB}$
Harmonic Distortion	$\leq 10\%$
Max Audio Output	3W


### **DSC Function**

Signal Format and Protocol	Comply with the ITU-R M.493-15 and M.541-10
Emission Type	G2B
Modulation Frequency	MARK(signal Y) : 1,300Hz $\pm$ 10Hz SPACE(signal B) : 2,100Hz $\pm$ 10Hz
Transmission Speed	1,200bps $\pm$ 30 x 10 <sup>-6</sup>

### **Dedicated DSC Receiver (WKR)**

Receive frequency	156.525MHz (channel 70)
Sensitivity	Error rate $\leq 1\%$ when receiving signal=1 $\mu\text{V}$

## APPENDIX 2 MENU TREE



## APPENDIX 3 CHANNEL TABLES

### ITU Channel Table (ITU-RR Appendix18)

CH	TX ( MHz)	RX ( MHz)	REMARK
1	156.050	160.650	
2	156.100	160.700	
3	156.150	160.750	
4	156.200	160.800	
5	156.250	160.850	
6	156.300	156.300	
7	156.350	160.950	
8	156.400	156.400	
9	156.450	156.450	
10	156.500	156.500	
11	156.550	156.550	
12	156.600	156.600	
13	156.650	156.650	
14	156.700	156.700	
15	156.750	156.750	Fixed at 1W
16	156.800	156.800	Distress, Safety and Calling
17	156.850	156.850	Fixed at 1W
18	156.900	161.500	
19	156.950	161.550	
1019	156.950	156.950	
2019	--	161.550	Transmission prohibited
20	157.000	161.600	
1020	157.000	157.000	
2020	--	161.600	Transmission prohibited
1027	157.350	157.350	
1028	157.400	157.400	
60	156.025	160.625	
61	156.075	160.675	
62	156.125	160.725	
63	156.175	160.775	
64	156.225	160.825	
65	156.275	160.875	
66	156.325	160.925	
67	156.375	156.375	
68	156.425	156.425	
69	156.475	156.475	
70	156.525	156.525	For DSC operation only
71	156.575	156.575	
72	156.625	156.625	
73	156.675	156.675	
74	156.725	156.725	
75	156.775	156.775	Fixed at 1W
76	156.825	156.825	Fixed at 1W
77	156.875	156.875	
78	156.925	161.525	
1078	156.925	156.925	
2078	--	161.525	Transmission prohibited
79	156.975	161.575	
1079	156.975	156.975	
2079	--	161.575	Transmission prohibited
87	157.375	157.375	
88	157.425	157.425	

**USA Channel Table (FCC 47 CFR Part 80: 80.215, 80.371 and 80.373)**

CH	TX ( MHz)	RX ( MHz)	REMARK
1001	156.050	156.050	
1005	156.250	156.250	
6	156.300	156.300	
1007	156.350	156.350	
8	156.400	156.400	
9	156.450	156.450	
10	156.500	156.500	
11	156.550	156.550	
12	156.600	156.600	
13	156.650	156.650	1w default
14	156.700	156.700	
15	-	156.750	Transmission prohibited
16	156.800	156.800	Distress, Safety and Calling
17	156.850	156.850	
1018	156.900	156.900	
1019	156.950	156.950	
20	157.000	161.600	
1020	157.000	157.000	
1022	157.100	157.100	
24	157.200	161.800	
25	157.250	161.850	
26	157.300	161.900	
27	157.350	161.950	
28	157.400	162.000	
1063	156.175	156.175	
1065	156.275	156.275	
1066	156.325	156.325	
67	156.375	156.375	1w default
68	156.425	156.425	
69	156.475	156.475	
70	156.525	156.525	For DSC operation only
71	156.575	156.575	1w default
72	156.625	156.625	
73	156.675	156.675	
74	156.725	156.725	
75	156.775	156.775	Fixed at 1w
76	156.825	156.825	Fixed at 1w
77	156.875	156.875	Fixed at 1w
1078	156.925	156.925	
1079	156.975	156.975	
1080	157.025	157.025	
84	157.225	161.825	
85	157.275	161.875	
86	157.325	161.925	
87	157.375	157.375	
88	157.425	157.425	

**CAN Cannel Table (INDUSTRY CANADA RBR-2)**

CH	TX ( MHz)	RX ( MHz)	REMARK
1	156.050	160.650	
1001	156.050	156.050	
2	156.100	160.700	
3	156.150	160.750	
4	156.200	160.800	
5	156.250	160.850	
1005	156.250	156.250	
6	156.300	156.300	
7	156.350	160.950	
1007	156.350	156.350	
8	156.400	156.400	
9	156.450	156.450	
10	156.500	156.500	
11	156.550	156.550	
12	156.600	156.600	
13	156.650	156.650	Fixed at 1W
14	156.700	156.700	
15	156.750	156.750	Fixed at 1W
16	156.800	156.800	Distress, Safety and Calling
17	156.850	156.850	Fixed at 1W
18	156.900	161.500	
1018	156.900	156.900	
19	156.950	161.550	
2019	--	161.550	Transmission prohibited
20	157.000	161.600	Fixed at 1W
1020	157.000	157.000	
2020	--	161.600	Transmission prohibited
21	157.050	161.650	
22	157.100	161.700	
23	157.150	161.750	
1023	--	161.750	Transmission prohibited
24	157.200	161.800	
25	157.250	161.850	
26	157.300	161.900	
2026	--	161.900	Transmission prohibited
27	157.350	161.950	
1027	157.350	157.350	
28	157.400	162.000	
60	156.025	160.625	
61	156.075	160.675	
62	156.125	160.725	
63	156.175	160.775	
1063	156.175	156.175	
64	156.225	160.825	
65	156.275	160.875	
1065	156.275	156.275	
66	156.325	160.925	
1066	156.325	156.325	
67	156.375	156.375	
68	156.425	156.425	

69	156.475	156.475	
70	156.525	156.525	For DSC operation only
71	156.575	156.575	
73	156.675	156.675	
74	156.725	156.725	
75	156.775	156.775	Fixed at 1W
76	156.825	156.825	Fixed at 1W
77	156.875	156.875	Fixed at 1W
78	156.925	161.525	
1078	156.925	156.925	
2078	--	161.525	Transmission prohibited
79	156.975	161.575	
1079	156.975	156.975	
2079	--	161.575	Transmission prohibited
80	157.025	161.625	
1080	157.025	157.025	
81	157.075	161.675	
82	157.125	161.725	
83	157.175	161.775	
84	157.225	161.825	
85	157.275	161.875	
86	157.325	161.925	
2086	--	161.925	Transmission prohibited
87	157.375	157.375	
88	157.425	157.425	

**IWW Cannel Table (ETSI EN 300 698 V2.2.1)**

CH	TX ( MHz)	RX ( MHz)	REMARK
1	156.050	160.650	
2	156.100	160.700	
3	156.150	160.750	
4	156.200	160.800	
5	156.250	160.850	
6	156.300	156.300	Fixed at 1W
7	156.350	160.950	
8	156.400	156.400	Fixed at 1W
9	156.450	156.450	
10	156.500	156.500	Fixed at 1W
11	156.550	156.550	Fixed at 1W
12	156.600	156.600	Fixed at 1W
13	156.650	156.650	Fixed at 1W
14	156.700	156.700	Fixed at 1W
15	156.750	156.750	Fixed at 1W
16	156.800	156.800	Distress, Safety and Calling
17	156.850	156.850	Fixed at 1W
18	156.900	161.500	
19	156.950	161.550	
1019	156.950	156.950	
2019	--	161.550	Transmission prohibited
20	157.000	161.600	
1020	157.000	157.000	
2020	--	161.600	Transmission prohibited
1027	157.350	157.350	
1028	157.400	157.400	
60	156.025	160.625	
61	156.075	160.675	
62	156.125	160.725	
63	156.175	160.775	
64	156.225	160.825	
65	156.275	160.875	
66	156.325	160.925	
67	156.375	156.375	
68	156.425	156.425	
69	156.475	156.475	
70	156.525	156.525	For DSC operation only
71	156.575	156.575	Fixed at 1W
72	156.625	156.625	Fixed at 1W
73	156.675	156.675	
74	156.725	156.725	Fixed at 1W
75	156.775	156.775	Fixed at 1W
76	156.825	156.825	Fixed at 1W
77	156.875	156.875	Fixed at 1W
78	156.925	161.525	
1078	156.925	156.925	
2078	--	161.525	Transmission prohibited
79	156.975	161.575	
1079	156.975	156.975	
2079	--	161.575	Transmission prohibited
87	157.375	157.375	
88	157.425	157.425	

**WX (Weather) Channel Table (FCC Rule 47CER80.371(c) and 80.373(f))**

CH	RX (MHz)	REMARK
WX1	162.550	NOAA Weather Channel / CANADA CMB Service
WX2	162.400	NOAA Weather Channel / CANADA CMB Service
WX3	162.475	NOAA Weather Channel / CANADA CMB Service
WX4	162.425	NOAA Weather Channel
WX5	162.450	NOAA Weather Channel
WX6	162.500	NOAA Weather Channel
WX7	162.525	NOAA Weather Channel
WX8	161.650	CANADA CMB Service
WX9	161.775	CANADA CMB Service
WX10	163.275	NOAA Weather Channel (Assigned only)

**Private Channels (For fishing or specially assigned channels)**

CH	TYPE	FREQUENCY (MHz)
001 - 200	Simplex and Semi-Duplex	155.000 - 163.500



## APPENDIX 4 SENTENCE DISCRPTION

### I/O Sentences

#### Input sentences (IEC 61162-1)

ACN, GGA, ZDA, GNS, RMC

#### Output sentence (IEC 61162-1)

ALF, ALC, HBT, ARC

### ACN – Alert command

\$--ACN,hhmmss.ss,aaa,x.x,x.x,c,a\*hh <CR><LF>



1. Time (see Note 1)
2. Manufacturer mnemonic code (see Note 2)
3. Alert Identifier (see Note 3)
4. Alert Instance, 1 to 999999 (see Note 4)
5. Alert command, A, Q, O or S (see Note 5)
6. Sentence status flag (see Note 6)
7. Checksum (same as below)

**NOTE 1:** Release time of the alert command. (e.g. for VDR purposes), optional can be a null field. Sender is allowed to use all alternatives defined in Alert Description Table. Receiver is allowed to ignore content of this field. If receiver does not ignore this field it should support all alternatives defined in Alert Description Table.

**NOTE 2:** Used for proprietary alerts defined by the manufacturer. For standardized alerts this should be a null field.

**NOTE 3:** The alert identifier is unique within a single alert source. The alert identifier is a variable length integer field of maximum 7-digit integer. It identifies the type of the alert e.g. a “lost target” alert. Standardized alerts use unique alert identifiers described in equipment standards. Number range 10000-9999999 is reserved for proprietary alerts. Alert Identifier examples: “001”, “2456789”, “245”.

**NOTE 4:** The alert instance identifies the current instance of an alert to distinguish alerts of the same type (Alert identifier) and from the same source (e.g. dangerous target). Alert instance is maximum 6-digit integer from 1 to 999999. The number of alert instance can be freely defined by the manufacturer as long as it is unique for one type of alert (alert identifier). It is not permitted to modify the alert instance within a life cycle of a distributed alert (from ‘active & unacknowledged’ state until ‘normal’ state is reached). It can be also a null field, when there is only one alert of that type.


**NOTE 5:** This should not be null field

acknowledge :	A
request / repeat information :	Q
responsibility transfer:	O
silence :	S

**NOTE 6:** This field should be “C” and should not be null field. This field indicates a command. A sentence without “C” is not a command.

### GGA -Global positioning system (GPS) fix data

\$--GGA,hhmmss.ss,llll.lll,a,yyyyy.yyy,a,x,xx,x.x,x.x,x,M,x.x,M,x.x,xxxx\*hh<CR><LF>



1. UTC of position
2. Latitude, N/S
3. Longitude, E/W
4. GPS quality indicator (see Note 1)
5. Number of satellite in use,00-12, may be different from the number in view
6. Horizontal dilution of precision
7. Antenna altitude above/below mean sea level (geoid), m
8. Geoidal separation, m (see Note 2)
9. Age of differential GPS data (see Note 3)
10. Differential reference station ID, 0000-1023

**NOTE 1:** All GPS quality indicators in headings 1 through 8 are considered “valid”. The heading “0” is the only “invalid” indicator. The GPS quality indicator field should not be a null field.


- 0 = fix not available or invalid
- 1 = GPS SPS mode
- 2 = differential GPS, SPS mode
- 3 = GPS PPS mode
- 4 = Real Time Kinematic. Satellite system used in RTK mode with fixed integers
- 5 = Float RTK. Satellite system used in RTK mode with floating solution
- 6 = Estimated (dead reckoning) mode
- 7 = Manual input mode
- 8 = Simulator mode

**NOTE 2:** Geoidal separation: the difference between the WGS-84 earth ellipsoid surface and mean sea level (geoid) surface, “-” = mean sea level surface below the WGS-84 ellipsoid surface.

**NOTE 3:** Time in seconds since last SC104 type 1 or 9 update, null field when DGPS is not used.

### ZDA - Time and date

\$--ZDA,hhmmss.ss,xx,xx,xxxx,xx,xx\*hh<CR><LF>




1. UTC
2. Day, 01 to 31 (UTC)

3. Month, 01 to 12 (UTC)
4. Year (UTC)
5. Local zone hours, 00h to ±13h
6. Local zone minutes, 00 to +59 (see Note)

**NOTE:** Local time zone is the magnitude of hours plus the magnitude of minutes added, with the sign of local zone hours, to local time to obtain UTC. Local zone is generally negative for East longitudes with local exceptions near the international date line.

### GNS - GNSS fix data

\$-- GNS, hhmmss.ss, llll.ll, a, yyyy.yy, a, c--c,xx,x.x,x.x,x.x,x.x,x.x,a \*hh<CR><LF>



1. UTC of position
2. Latitude, N/S
3. Longitude, E/W
4. Mode indicator (see Note 1)
5. Total number of satellites in use, 00-99
6. HDOP (see Note 2)
7. Antenna altitude, m, re: mean-sea-level (geoid)
8. Geoidal separation, m (see Note 3)
9. Age of differential data (see Note 4)
10. Differential reference station ID (see Note 4)
11. Navigational status indicator (see Note 5)

**NOTE 1:** Mode indicator. A variable length valid character field type with the first three characters currently defined. The first character indicates the use of GPS satellites, the second character indicates the use of GLONASS satellites and the third indicate the use of Galileo satellites. If another satellite system is added to the standard, the mode indicator will be extended to four characters, new satellite systems should always be added on the right, so the order of characters in the mode indicator is: GPS, GLONASS, Galileo, other satellite systems in the future. The characters should take one of the following values:

- A = Autonomous. Satellite system used in non-differential mode in position fix;
- D = Differential. Satellite system used in differential mode in position fix;
- E = Estimated (dead reckoning) mode;
- F = Float RTK. Satellite system used in real time kinematic mode with floating integers;
- M = Manual input mode;
- N = No fix. Satellite system not used in position fix, or fix not valid;
- P = Precise. Satellite system used in precision mode. Precision mode is defined as: no deliberate degradation (such as selective availability) and higher resolution code (P-code) is used to compute position fix. P is also used for satellite system used in multi-frequency, SBAS or Precise Point Positioning (PPP) mode;
- R = Real Time Kinematic. Satellite system used in RTK mode with fixed integers;

S = Simulator mode.

The mode indicator should not be a null field.

**NOTE 2:** HDOP calculated using all the satellites (GPS, GLONASS, Galileo and any future satellites) used in computing the solution reported in each GNS sentence.

**NOTE 3:** Geoidal Separation: the difference between the earth ellipsoid surface and mean-sea-level (geoid) surface defined by the reference datum used in the position solution, “-” = mean-sea-level surface below ellipsoid.

The reference datum may be specified in the DTM sentence.

**NOTE 4:** Age of differential data and Differential Reference Station ID:

a) When the talker is GN and more than one of the satellite systems are used in differential mode, then the “Age of differential data” and “Differential reference station ID” fields should be null. In this case, the “Age of differential data” and “Differential reference station ID” fields should be provided in following GNS sentences with talker IDs of GP, GL, etc. These following GNS messages should have the latitude, N/S, longitude, E/W, altitude, geoidal separation, mode, and HDOP fields null. This indicates to the listener that the field is supporting a previous \$GNGNS sentence with the same time tag. The “Number of satellites” field may be used in these following sentences to denote the number of satellites used from that satellite system.

The Differential Reference station ID may be the same or different for the different satellite systems.

b) Age of Differential Data For GPS Differential Data:

This value is the average age of the most recent differential corrections in use. When only RTCM SC104 Type 1 corrections are used, the age is that of the most recent Type 1 correction. When RTCM SC104 Type 9 corrections are used solely, or in combination with Type 1 corrections, the age is the average of the most recent corrections for the satellites used. Null field when Differential GPS is not used.

For GLONASS Differential Data:

This value is the average age of the most recent differential corrections in use. When only RTCM SC104 Type 31 corrections are used, the age is that of the most recent Type 31 correction. When RTCM SC104 Type 34 corrections are used solely, or in combination with Type 31 corrections, the age is the average of the most recent corrections for the satellites used. Null field when differential GLONASS is not used.

For Galileo Differential Data:

This value is the average age of the most recent differential corrections in use. When only RTCM SC104 Type 41 corrections are used, the age is that of the most recent Type 41 correction. When RTCM SC104 Type 42 corrections are used solely, or in combination with Type 41 corrections, the age is the average of the most recent corrections for the satellites used. Null field when differential Galileo is not used.

**NOTE 5:** The navigational status indicator is according to IEC 61108 requirements on ‘Navigational (or Failure) warnings and status indications’. This field should not be a NULL field and the character should take one of the following values:

S = Safe when the estimated positioning accuracy (95 % confidence) is within the selected accuracy level corresponding to the actual navigation mode, and integrity is available and within the requirements for the actual navigation mode, and a new valid position has been calculated within 1 s for a conventional craft and 0,5 s for a high speed craft;

C = Caution when integrity is not available;


U = Unsafe when the estimated positioning accuracy (95% confidence) is less than the selected accuracy level corresponding to the actual navigation mode, and/or integrity is available but exceeds the requirements for the actual navigation mode, and/or a new valid position has not been calculated within 1 s for a conventional craft and 0,5 s for a high speed craft;

V = Navigational status not valid, equipment is not providing navigational status indication.



**ALF - Alert sentence**

\$--ALF, x, x, x, hhmmss.ss, a, a, a, aaa, x.x, x.x, x.x, x,c---c\*hh <CR><LF>



1. Total number of ALF sentences for this message, 1 to 2 (see Note 1)
2. Sentence number, 1 to 2 (see Note 1)
3. Sequential message identifier, 0 to 9 (see Note 2)
4. Time of last change (see Note 3)
5. Alert category, A, B or C (see Note 4)
6. Alert priority, E, A, W or C (see Note 5)
7. Alert state, A, S, R, O, U or D (see Note 6)
8. Manufacturer mnemonic code (see Note 7)
9. Alert identifier (see Note 8)
10. Alert instance, 1 to 999999 (see Note 9)
11. Revision counter, 1 to 99 (see Note 10)
12. Escalation counter, 0 to 9 (see Note 11)
13. Alert text (see Note 12)

**NOTE 1:** The first field specifies the total number of sentences used for a message, minimum value 1. The second field identifies the order of this sentence in the message, minimum value 1, these cannot be null fields. When the sentence number is 2, the following Alert category, Alert priority and Alert state can be null fields.

**NOTE 2:** The sequential message identifier relates all sentences that belong to a group of multiple sentences (i.e. message). Multiple sentences (see Note 1) with the same sequential message identifier, make up one message.

**NOTE 3:** Time should represent the last time the data within the alert message has changed. For example changing the alert text by in-/decrementing a contained counter or count down should cause a revision of alert message and a new time. Time is an optional field. The time-field is additional information about when this happened and not used for decision making. There is no mandatory requirement for time synchronization between the equipment. It should be either a null field (if not used) or UTC (if used). Sender is allowed to use all alternatives defined in Alert Description Table. Receiver is allowed to ignore content of this field. If the receiver does not ignore this field it should support all alternatives defined in Alert Description Table.

**NOTE 4:** The alert category is in compliance with the category definition as described in INS Performance Standard (MSC.252(83)) and Bridge Alert Management Performance Standard (MSC.302 (87)):

- A, Category A: Alerts where information at operator unit directly assigned to the function generating the alert is necessary, as decision support for the evaluation of the alert-related condition, e.g. graphical information of danger of collision or graphical information of danger of grounding.
- B, Category B: Alerts where no additional information for decision support is necessary besides the information which can be presented using alert source and alert description text.
- C, Category C: Alerts that cannot be acknowledged on the bridge but for which information is required about the status and treatment of the alerts, e.g., certain alerts from the engine.

**NOTE 5:** Alert priority:    Emergency Alarm:    E, for use with Bridge alert management  
                                  Alarm:                                    A  
                                  Warning:                                W  
                                  Caution:                              C

**NOTE 6:** The alert state transition is defined in Annex J

active – unacknowledged:    V  
 active – silenced:                S  
 active – acknowledged or active: A  
 active – responsibility transferred: O  
 rectified – unacknowledged:    U  
 normal:                                N

**NOTE 7:** Used for proprietary alerts defined by the manufacturer. For standardized alerts this should be a null field.

**NOTE 8:** The alert identifier is unique within a single alert source. The alert identifier is a variable length integer field of maximum 7-digit integer. It identifies the type of the alert e.g. a “lost target” alert. Standardized alerts use unique alert identifiers described in equipment standards. Number range 10000-9999999 is reserved for proprietary alerts. Alert Identifier examples: “001”, “2456789”, “245”.

**NOTE 9:** The alert instance identifies the current instance of an alert to distinguish alerts of the same type (Alert identifier) and from the same source (e.g. dangerous target). Alert instance is maximum 6-digit integer from 1 to 999999. The number of alert instance can be freely defined by the manufacturer as long as it is unique for one type of alert (alert identifier). It is not permitted to modify the alert instance within a life cycle of a distributed alert (from ‘active & unacknowledged’ state until ‘normal’ state is reached). It can be also a null field, when there is only one alert of that type.


**NOTE 10:** The revision counter is the main method to follow up-to-date status. Revision counter is also unique for each instance of alert. Revision counter starts with 1 and the step for increment is 1. The count resets to 1 after 99 is used. Revision counter increments on each change of content of any field of the alert.

**NOTE 11:** The escalation counter is presenting the number of alert escalations after time expiration during the state active-unacknowledged. The escalation counter starts with 0 and the step for increment is 1. The count resets to 1 after 9 is used. The alert escalation can be the escalation from warning into warning (activation of audible signal only), the escalation from warning to alarm or the escalation from alarm to alarm with activation of back-up navigator alarm

**NOTE 12:** This field is used for Alert title which is mandatory and for additional alert description which is optional.

- The first ALF sentence transmits the Alert title. Alert title is maximum 16 characters short form of the alert text.
- The optional second ALF sentence transmits the additional alert description. Additional alert description is the long description of the alert. The additional alert description contains more information for decision making (i.e. alert description text).
- The second ALF sentence uses null fields for Time of last change, Alert category, Alert priority, and Alert state to allow longer text. The actual number of valid characters should be such that the total number of characters in a sentence does not exceed the “82”-character limit.
- Some equipment standards specify alert text longer than 16 characters (for example the AIS standard has defined some alerts to be coded with ALR sentence and with text longer than 16 characters). In such cases the first ALF sentence is used for the first 16 characters of the alert text as alert title and the second ALF sentence to carry the full alert text.

### ALC - Cyclic alert list



1. Total number of sentences for this message, 01 to 99 (see Note 1)
2. Sentence number, 01 to 99 (see Note 1)
3. Sequential message identifier, 00 to 99 (see Note 2)
4. Number of alert entries (see Note 3)
5. Alert entry 1 (see Note 4)
6. Additional Alert entries (see Note 4)
7. Alert entry n (see Note 4)

**NOTE 1:** The first field specifies the total number of sentences used for a message, minimum value 1. The second field identifies the order of this sentence in the message, minimum value 1, These cannot be null fields.

**NOTE 2:** The sequential message identifier relates all sentences that belong to a group of multiple sentences (i.e. message). Multiple sentences (see Note 1) with the same sequential message identifier, make up one message.


**NOTE 3:** Contains the number of alert entries transported within this sentence.

**NOTE 4:** Alert entry 0 – n: Each alert entry consists of four fields:

- Manufacturer Identifier (see ALF Manufacturer Identifier)
- Alert Identifier (see ALF Alert Identifier)
- Alert instance (see ALF Alert instance)
- Revision Counter (see ALF Revision Counter)

Each entry identifies a certain alert with a certain state. It is not allowed that an alert entry is split between two ALC sentences.

### HBT – Heartbeat supervision sentence



1. Configured repeat interval (see Note 1)
2. Equipment status (see Note 2)
3. Sequential sentence identifier (see Note 3)

**NOTE 1:** Configured autonomous repeat interval in seconds. This field should be set to NULL in response to a query if this feature is supported.

**NOTE 2:** Equipment in normal operation A = yes, V = no


This field can be used to indicate the current equipment status. This could be the result of an built-in integrity testing function.

**NOTE 3:** The sequential sentence identifier provides a message identification number from 0 to 9 that is sequentially assigned and is incremented for each new sentence. The count resets to 0 after 9 is used.



**ARC - Alert command refused**

\$--ARC, hhmmss.ss, aaa, x.x, x.x, c\*hh <CR><LF>



1. Time (see Note 1)
2. Manufacturer mnemonic code (see Note 2)
3. Alert identifier (see Note 3)
4. Alert instance, 1 to 999999 (see Note 4)
5. Refused alert command, A, Q,O or S (see Note 5)

**NOTE 1:** Release time of the Alert Command Refused. (e.g. for VDR purposes), optional, can be a null field. Sender is allowed to use all alternatives defined in Alert Description Table. Receiver is allowed to ignore content of this field. If receiver does not ignore this field it should support all alternatives defined in Alert Description Table.

**NOTE 2:** Used for proprietary alerts defined by the manufacturer. For standardized alerts this should be a null field.

**NOTE 3:** The alert identifier is unique within a single alert source. The alert identifier is a variable length integer field of maximum a 7-digit integer. It identifies the type of the alert, e.g. a “lost target” alert. Standardized alerts use unique alert identifiers described in equipment standards. Number range 10000-9999999 is reserved for proprietary alerts. Alert Identifier examples: “001”, “2456789”, “245”.


**NOTE 4:** The alert instance identifies the current instance of an alert to distinguish alerts of the same type (Alert identifier) and from the same source (e.g. dangerous target). Alert instance is maximum a 6-digit integer from 1 to 999999. The number of alert instance can be freely defined by the manufacturer as long as it is unique for one type of alert (alert identifier). It is not permitted to modify the alert instance within a life cycle of a distributed alert (from ‘active and unacknowledged’ state until ‘normal’ state is reached). It can be also a null field, when there is only one alert of that type.

**NOTE 5:** Refused Alert Command: Indicates refused “Alert command” of corresponding ACN sentence. This should not be a null field.

acknowledge:	A
request / repeat information:	Q
responsibility transfer:	O
silence:	S


## APPENDIX 5 INSTALLATION DRAWINGS

NO.	DATE	REVISION & DESCRIPTION	CHECKED	SIGNATURE
△				




APPLICATION						NVR-3000 SYSTEM DIAGRAM					
DATE	ITEM	SCALE	UNIT	PROJ.	VIPR	SIZE					
		1/1	mm			A4					
CHECKED											
DRAWING											
DWG. NO.	NVR3000-ID-001										
 <b>NEW SUNRISE CO., LTD.</b>											






TOP VIEW




FRONT VIEW




SIDE VIEW


NO.	DATE	REVISION & DESCRIPTION	REVIEWED SIGNATURE	CHECKED SIGNATURE
△				

APPLICATION NVR-3000 DIMENSION DRAWING				
DATE	ITEM	V/P	SIZE	A4
APPROVAL	SCALE	1:1	UNIT	mm
CHECKED	PROJ. PART	NSR	DATE	2008.05.20
DRAWING	DRAWING NO. NVR3000-ID-003			
 <b>NSR</b> NEW SUNRISE CO., LTD. m a p i n e				


NO.	DATE	REVISION & DESCRIPTION	REVIEWED	CHECKED
△				
		SIGNATURE		



FRONT VIEW



SIDE VIEW








BOTTOM VIEW

NOTE:

1. USE SELF-TAPPING SCREWS M5X20 FOR FIXING THE UNIT
2. 80MM IS MINIMUM SPACE FOR OPERATION AND CABLING.
3. TABLE MOUNT TYPE.

APPLICATION		NVR-3000 MOUNTING DRAWING (TABLE TYPE)		
DATE	ITEM	SCALE	UNIT	PROJ. PARTIAL
		1:1	mm	NSR
APPROVAL	SIZE	VPR		
CHECKED	SIZE	L44		
DRAWING	NEW SUNRISE CO., LTD.			
DWG. NO.	NVR3000D-004			





APPLICATION





HANDSET SIZE DRAWING

DATE	ITEM	NHR-1500	SIZE	A4
APPROVAL	SCALE	1/1	UNIT	mm
CHECKED				
DRAWING				
DWG NO.		NVR3000-ID-006		




NEW SUNRISE CO., LTD.





APPLICATION **HANDSET MOUNTING DRAWING**

DATE	ITEM	NHR-1500	SIZE	A4
APPROVAL	SCALE	1/1	UNIT	mm
CHECKED	DRAWING	 <b>NEW SUNRISE CO., LTD.</b>		
DWG NO.	NVR3000-ID-007			